



Multi-Spindle Lathe Spare Parts & Equipment

CATALOGUE 2026

Gildemeister GM16 · GM20 · AS · GS · GM32 · GM35 · GM42

Tooling attachments for Wickman, Schütte and Mori-Say

1,817 part numbers

Price on request · sales@dhg-usa.com

An alternative to traditional OEM channels

Multi-spindle lathes stay in production for decades. Keeping them running means finding the right component quickly, at a cost that makes sense against the value of the machine.

DHG Tech Inc. offers an alternative route to the traditional OEM channel: a catalogue of more than 1,800 part numbers for Gildemeister multi-spindle lathes, together with tooling attachments compatible with Wickman, Schütte and Mori-Say machines. Components are manufactured in Europe by specialists with decades of hands-on experience on this type of equipment, and are built to the original dimensional and functional standards — not generic reproductions.

You deal with a New York corporation: quotation, order and commercial relationship all sit with DHG Tech Inc.

Delivered to you as a domestic shipment

Parts are imported into the United States by DHG Tech Inc. and forwarded to you by our customs agent. What arrives at your facility is a domestic delivery: no customs paperwork on your side, no separate duty or clearance invoice to reconcile, one supplier and one purchase order.

How pricing works

Prices are quoted on request rather than published as a fixed list. Every enquiry is priced individually against the specific part, the quantity and the urgency of the requirement, which gives you a sharper number than a generic list price would.

- 1 Identify the part number in this catalogue, or describe the component and the machine model.
- 2 Send your request to sales@dhg-usa.com or through the form at www.dhg-usa.com.
- 3 We reply with price, availability and lead time.

Reading this catalogue

Descriptions are given in English for quick identification, with the original Italian technical description shown underneath in grey where available. Tooling attachments are listed by description only, as no OEM part numbers exist for those items.

Contents

Section	Part numbers
Gildemeister GM16 / GM20 / AS / GS Spare Parts	1,059
Gildemeister GM32 / GM35 / GM42 Spare Parts	565
Equipment & Tooling Attachments	193
Total	1,817

Gildemeister GM16 / GM20 / AS / GS Spare Parts

1,059 part numbers • price on request

Chucks, Collets & Bar Clamping		207
0125202	BEARING for BELL HOUSING open/close COLLET GILD.AS16-AS/GS/GM20 IT: CUSCINETTO x CAMPANA A/C PINZA GILD.AS16-AS/GS/GM20	
0810013	BELL HOUSING IT: CAMPANA	
1417006	BELL HOUSING IT: CAMPANA	
0810035	BELL HOUSING ENGAGEMENT L=12 IT: CAMPANA INNESTO L=12	
1517001	BELL HOUSING ENGAGEMENT L=20 IT: CAMPANA INNESTO L=20	
0810202/35	BELL HOUSING SPECIAL Z=35 IT: CAMPANA SPECIALE Z=35	
0810201/54	BELL HOUSING SPECIAL Z=54 IT: CAMPANA SPECIALE Z=54	
0810202	BELL HOUSING Z=52 IT: CAMPANA Z=52	
20093602	BELL HOUSING for CLOSURE REINFORCED GILD.AS16/20 IT: CAMPANA x CHIUSURA RINFORZATA GILD.AS16/20	
0853111	BELL HOUSING for ENGAGEMENT CLUTCHES IT: CAMPANA x INNESTO FRIZIONI	
0810201	BELL HOUSING for ENGAGEMENT Z=38 IT: CAMPANA x INNESTO Z=38	
3160103	BELL HOUSING for GILDEMEISTER GM20 STOP SPINDLE IT: CAMPANA x GILDEMEISTER GM20 STOP MANDRINO	
0801351 R	BELL HOUSING open/close COLLET GILD. AS16-AS/GS/GM20 R IT: CAMPANA A/C PINZA GILD. AS16-AS/GS/GM20 R	
0801351	BELL HOUSING open/close. COLLET GILD.AS16-AS/GS/GM20 IT: CAMPANA A/C. PINZA GILD.AS16-AS/GS/GM20	
3101137	BOOT COVER for SPINDLE IT: CUFFIA x MANDRINO	
4501112	BOOT COVER for SPINDLE IT: CUFFIA x MANDRINO	
1501702	BOOT COVER for SPINDLE GILD.GS20 IT: CUFFIA x MANDRINO GILD.GS20	
0801015	BUSHING SPLINED for ADJUSTMENT DRAW ROD COUNTER-COLLET GILD.AS/GS/GM20 IT: BOCCOLA SCANALATA x REGISTRAZIONE TIRANTE CONTROPINZA GILD.AS/GS/GM20	
0814006	BUSHING SPLINED for front spindle AS/GS/GM20 IT: BUSSOLA SCANALATA x MANDRINO FRONTALE AS/GS/GM20	
3125114	BUSHING for front spindle GILD.AS/GS/GM20 (to be bored 15.25.104) IT: BOCCOLA x MANDRINO FRONTALE GILD.AS/GS/GM20 (DA BARENARE 15.25.104)	
3125114G	BUSHING for front spindle GILD.AS/GS/GM20 (to be bored 15.25.104) IN CAST IRON IT: BOCCOLA x MANDRINO FRONTALE GILD.AS/GS/GM20 (DA BARENARE 15.25.104) IN GHISA	
3118154	CLAMP for CLAMPING front spindles GILD.GM20 IT: MORSETTO x BLOCCAGGIO MANDRINI FRONTALI GILD.GM20	
1558254	CLAMP for pick-up spindle PNEUMATIC IT: MORSETTO x MANDRINO DA RIPRESA PNEUMATICO	
2245H400	CLUTCH MECHANICAL DOUBLE for GILD. GS/GM20 STOP SPINDLE (07.23.70) IT: FRIZIONE MECCANICA DOPPIA x GILD. GS/GM20 STOP MANDRINO (07.23.70)	

0201202	COLLAR NUT IT: GHIERA
0501151	COLLAR NUT IT: GHIERA
0505005	COLLAR NUT IT: GHIERA
0516103	COLLAR NUT IT: GHIERA
0517008	COLLAR NUT IT: GHIERA
0801016	COLLAR NUT IT: GHIERA
0801105	COLLAR NUT IT: GHIERA
1103006	COLLAR NUT IT: GHIERA
1501008	COLLAR NUT IT: GHIERA
1521106	COLLAR NUT IT: GHIERA
1558117	COLLAR NUT IT: GHIERA
1558124	COLLAR NUT IT: GHIERA
1558151	COLLAR NUT IT: GHIERA
2802207	COLLAR NUT IT: GHIERA
3126129	COLLAR NUT IT: GHIERA
3126130	COLLAR NUT IT: GHIERA
3158104	COLLAR NUT IT: GHIERA
3158260	COLLAR NUT IT: GHIERA
4526285	COLLAR NUT IT: GHIERA
4558270	COLLAR NUT IT: GHIERA
0201203	COLLAR NUT CARRIER BUSHING GUIDE BAR GILD.AS16-AS/GS/GM20 IT: GHIERA PORTA BUSSOLA GUIDA BARRA GILD.AS16-AS/GS/GM20
0124103	COLLAR NUT DOUBLE X EXTENSION front spindles IT: GHIERA DOPPIA X PROLUNGA MANDRINI FRONTALI
3101146	COLLAR NUT FOR SPINDLE MAIN GILD.AS/GS/GM20 (31.01.416) IT: GHIERA PER MANDRINO PRINCIPALE GILD.AS/GS/GM20 (31.01.416)
1558109	COLLAR NUT FOR pick-up spindle PNEUMATIC IT: GHIERA PER MANDRINO DA RIPRESA PNEUMATICO
1525204	COLLAR NUT IN BRONZE for HEXAGON IT: GHIERA IN BRONZO x ESAGONO
0801016S	COLLAR NUT SPECIAL EXTENDED for LOADER P. CUCCHI IT: GHIERA SPECIALE PROLUNGATA x CARICATORE P. CUCCHI
1501605S	COLLAR NUT SPECIAL EXTENDED for LOADER P. CUCCHI IT: GHIERA SPECIALE PROLUNGATA x CARICATORE P. CUCCHI
0801352	COLLAR NUT for BELL HOUSING GILD.AS/GS/GM20 IT: GHIERA x CAMPANA GILD.AS/GS/GM20

20093605	COLLAR NUT for CLOSURE REINFORCED GILD.AS16/20 IT: GHIERA x CHIUSURA RINFORZATA GILD.AS16/20
1518203	COLLAR NUT for COUPLING front spindles IT: GHIERA x GIUNTO MANDRINI FRONTALI
1501605	COLLAR NUT for DRAW ROD BAR CLAMP VARIANT 25mm IT: GHIERA x TIRANTE STRINGIBARRA VARIANTE 25mm
1517016	COLLAR NUT for SHAFT PULLEY IT: GHIERA x ALBERO PULEGGIA
0801010	COLLAR NUT for SPINDLE IT: GHIERA x MANDRINO
0801102	COLLAR NUT for SPINDLE GILD.AS16/20 IT: GHIERA x MANDRINO GILD.AS16/20
4501111	COLLAR NUT for SPINDLE GILD.GM20 IT: GHIERA x MANDRINO GILD.GM20
4526102	COLLAR NUT for STOP POSITIVE front spindle FIXED IT: GHIERA x FERMO POSITIVO MANDRINO FRONTALE FISSO
1526007	COLLAR NUT for STOP POSITIVE front spindle ROTATING IT: GHIERA x FERMO POSITIVO MANDRINO FRONTALE ROTANTE
3158102	COLLAR NUT for STUB SHAFT CARRIER BEARINGS for ACCUMULATOR PICK-UP PNEUMATIC GILD.GS/GM20 IT: GHIERA x ALBERINO PORTA CUSCINETTI x POLMONE PICK-UP PNEUMATICO GILD.GS/GM20
4558271	COLLAR NUT for STUB SHAFT CARRIER BEARINGS for ACCUMULATOR PICK-UP PNEUMATIC GILD.GS/GM20 IT: GHIERA x ALBERINO PORTA CUSCINETTI x POLMONE PICK-UP PNEUMATICO GILD.GS/GM20
1518107	COLLAR NUT for front spindle GILD.AS/GS/GM20 IT: GHIERA x MANDRINO FRONTALE GILD.AS/GS/GM20
0130001	COLLAR NUT for front spindles IT: GHIERA x MANDRINI FRONTALI
1558111	COLLAR NUT for pick-up spindle PNEUMATIC IT: GHIERA x MANDRINO DA RIPRESA PNEUMATICO
1518202	COLLET CLAMPING front spindles IT: PINZA BLOCCAGGIO MANDRINI FRONTALI
0801401	COMPENSATOR for DRAW ROD collet holder GILD.AS16 AS/GS/GM20 IT: COMPENSATORE x TIRANTE PORTAPINZA GILD.AS16 AS/GS/GM20
0525600	CONNECTING ROD for pick-up spindle AS16 IT: BIELLA x MANDRINO DA RIPRESA AS16
3118153	COUPLING for CLAMPING front spindles GILD.GM20 IT: GIUNTO x BLOCCAGGIO MANDRINI FRONTALI GILD.GM20
0847008	CYLINDER for pick-up spindle PNEUMATIC GILD.AS16 P.6 IT: CILINDRO x MANDRINO DA RIPRESA PNEUMATICO GILD.AS16 P.6
1558144	CYLINDER for pick-up spindle PNEUMATIC GILD.AS20 IT: CILINDRO x MANDRINO DA RIPRESA PNEUMATICO GILD.AS20
1501352	DRAW ROD BAR CLAMP GILD.AS/GS/GM20 IT: TIRANTE STRINGIBARRA GILD.AS/GS/GM20
0853151	DRAW ROD BAR CLAMP GILD.AS/GS/GM20 STOP SPINDLE IT: TIRANTE STRINGIBARRA GILD.AS/GS/GM20 STOP MANDRINO
1501601	DRAW ROD BAR CLAMP VARIANT 25mm IT: TIRANTE STRINGIBARRA VARIANTE 25mm
1560801	DRAW ROD BAR CLAMP for GILD.AS/GS/GM20 VAR.25 STOP SPINDLE IT: TIRANTE STRINGIBARRA x GILD.AS/GS/GM20 VAR.25 STOP MANDRINO
1501351	DRAW ROD BAR PUSHER GILD.AS/GS/GM20 IT: TIRANTE SPINGIBARRA GILD.AS/GS/GM20
0853152	DRAW ROD BAR PUSHER GILD.AS/GS/GM20 STOP SPINDLE IT: TIRANTE SPINGIBARRA GILD.AS/GS/GM20 STOP MANDRINO
1560802	DRAW ROD BAR PUSHER GILD.AS/GS/GM20 VARIANT 25 STOP SPINDLE IT: TIRANTE SPINGIBARRA GILD.AS/GS/GM20 VARIANTE 25 STOP MANDRINO
1501602	DRAW ROD BAR PUSHER VARIANT 25mm IT: TIRANTE SPINGIBARRA VARIANTE 25mm

4501011	DRAW ROD CLOSURE VARIANT 25mm for GILD.AS/GS/GM20 STOP SPINDLE IT: TIRANTE CHIUSURA VARIANTE 25mm x GILD.AS/GS/GM20 STOP MANDRINO
4501018	DRAW ROD FEED (COMPLETE) VARIANT 25mm for GILD.AS/GS/GM20 STOP SPINDLE IT: TIRANTE AVANZAMENTO (COMPLETO) VARIANTE 25mm x GILD.AS/GS/GM20 STOP MANDRINO
4501016V1	DRAW ROD FEED (PARTIAL) VARIANT 25mm for GILD.AS/GS/GM20 IT: TIRANTE AVANZAMENTO (PARZIALE) VARIANTE 25mm x GILD.AS/GS/GM20
0847027	DRAW ROD INTERNAL for PICK-UP GILD.AS16 IT: TIRANTE INTERNO x PICK-UP GILD.AS16
0508009	DRAW ROD for SLIDES RADIAL IT: TIRANTE x SLITTE RADIALI
3119105	DRAW ROD for STOP BAR GILD.GS/GM20 IT: TIRANTE x FERMO BARRA GILD.GS/GM20
0514007	DRAW ROD for front spindles IT: TIRANTE x MANDRINI FRONTALI
3158200	EJECTOR pick-up spindle AS16 for ROD Ø 8 IT: ESPULSORE MANDRINO DA RIPRESA AS16 x ASTA Ø 8
0509105/60	EXTENSION for front spindles A=60 mm IT: PROLUNGA x MANDRINI FRONTALI A=60 mm
0509105/75	EXTENSION for front spindles A=75 mm IT: PROLUNGA x MANDRINI FRONTALI A=75 mm
0509105/90	EXTENSION for front spindles A=90 mm IT: PROLUNGA x MANDRINI FRONTALI A=90 mm
3160104	FORK for GILDEMEISTER GM20 STOP SPINDLE IT: FORCELLA x GILDEMEISTER GM20 STOP MANDRINO
0502009	FORK for OPENING/CLOSURE COLLET GILD. AS16/20 GS/GM20 IT: FORCELLA x APERTURA/CHIUSURA PINZA GILD. AS16/20 GS/GM20
0111029	INDEX for LEVERS front spindles GILD.AS/GS/GM20 (20004224) IT: INDICE x LEVE MANDRINI FRONTALI GILD.AS/GS/GM20 (20004224)
4524184	INSERT for LEVER AP/CH COLLETS MANUAL GM20 IT: TASSELLO x LEVA AP/CH PINZE MANUALE GM20
1525303	INSERT for SMALL SUPPORT front spindles GILD. AS16-AS/GS/GM20 IT: TASSELLO x SUPPORTINO MANDRINI FRONTALI GILD. AS16-AS/GS/GM20
1525303 M6	INSERTS M6 for SMALL SUPPORT front spindles GILD. AS16-AS/GS/GM20 IT: TASSELLI M6 x SUPPORTINO MANDRINI FRONTALI GILD. AS16-AS/GS/GM20
0514012	KEY CONNECTING ROD front spindles GILD.20/35 IT: CHIAVETTA BIELLA MANDRINI FRONTALI GILD.20/35
0101510	KEY EXTERNAL for collet sleeve GILD.AS16-AS/GS/GM20 IT: CHIAVETTA ESTERNA x BICCHIERE P.PINZA GILD.AS16-AS/GS/GM20
1501608	KEY INTERNAL for collet sleeve GILD.AS/GS/GM20 VARIANT 25mm IT: CHIAVETTA INTERNA x BICCHIERE P.PINZA GILD.AS/GS/GM20 VARIANTE 25mm
1401202	KEY INTERNAL for collet sleeve GILD.AS16-AS/GS/GM20 IT: CHIAVETTA INTERNA x BICCHIERE P.PINZA GILD.AS16-AS/GS/GM20
1558112	KEY REAR for pick-up spindle PNEUMATIC IT: CHIAVETTA POSTERIORE x MANDRINO DA RIPRESA PNEUMATICO
1518204	KEY for CLAMPING COLLET front spindle GILD.20 / CONTROL AXIAL front spindle GILD.GM35 (30010209) IT: CHIAVETTA x BLOCCAGGIO PINZA MANDRINO FRONTALE GILD.20 / COMANDO ASSIALE MANDRINO FRONTALE GILD.GM35 (30010209)
1049015	KEY for COLLET M.D.R. PNEUMATIC GILD.AS/GS20 IT: CHIAVETTA x PINZA M.D.R. PNEUMATICO GILD.AS/GS20
0847026	KEY for COLLET PICK-UP AS16 IT: CHIAVETTA x PINZA PICK-UP AS16
1525009	KEY for SMALL SUPPORT front spindles GILD. AS16-AS/GS/GM20 IT: CHIAVETTA x SUPPORTINO MANDRINI FRONTALI GILD. AS16-AS/GS/GM20
0801013	KEY for SPINDLE GILD.AS/GS/GM20 IT: CHIAVETTA x MANDRINO GILD.AS/GS/GM20

1558105	KEY for SUPPORT pick-up spindle PNEUMATIC IT: CHIAVETTA x SUPPORTO MANDRINO DA RIPRESA PNEUMATICO
1558136	KEY for pick-up spindle IT: CHIAVETTA x MANDRINO DA RIPRESA
3160135	LATCH for POSITIONING GILD.AS/GS/GM20 STOP SPINDLE IT: CHIAVISTELLO x POSIZIONAMENTO GILD.AS/GS/GM20 STOP MANDRINO
3122112	LEVER front spindle GILD.GM20 POS.1-6 (F=Ø24mm) IT: LEVA MANDRINO FRONTALE GILD.GM20 POS.1-6 (F=Ø24mm)
3122113	LEVER front spindle GILD.GM20 POS.2-3 (F=Ø24mm) IT: LEVA MANDRINO FRONTALE GILD.GM20 POS.2-3 (F=Ø24mm)
3122114	LEVER front spindle GILD.GM20 POS.4 (F=Ø24mm) (08.07.003) IT: LEVA MANDRINO FRONTALE GILD.GM20 POS.4 (F=Ø24mm) (08.07.003)
3122115	LEVER front spindle GILD.GM20 POS.5 (F=Ø24mm) IT: LEVA MANDRINO FRONTALE GILD.GM20 POS.5 (F=Ø24mm)
1504111	LEVER open/close COLLET IT: LEVA A/C PINZA
1560401	LEVER open/close COLLET GILD.GS20 STOP SPINDLE IT: LEVA A/C PINZA GILD.GS20 STOP MANDRINO
0535002	LEVER open/close COLLET MANUAL for GM20 IT: LEVA A/C PINZA MANUALE x GM20
0502001	PIN for A./C. COLLET IT: PERNO x A./C. PINZA
0502012	PIN for BEARING BELL HOUSING GILD.AS16/20-GS20-GM20/32/35 IT: SPINA x CUSCINETTO CAMPANA GILD.AS16/20-GS20-GM20/32/35
0525653	PIN for CONTROL SPINDLE IT: SPINA x COMANDO MANDRINO
3160105	PIN for STOP SPINDLE IT: PERNO x ARRESTO MANDRINO
1558128	PIN for pick-up spindle PNEUMATIC IT: SPINA x MANDRINO DA RIPRESA PNEUMATICO
0847013	PIN pick-up spindle PNEUMATIC IT: SPINA MANDRINO DA RIPRESA PNEUMATICO
0810040	PLUG CONTROL ROTATION SPINDLES GILD. GM20 IT: TAPPO COMANDO ROTAZIONE MANDRINI GILD. GM20
1558114	QUILL for pick-up spindle AS/GS20 PNEUMATIC IT: CANNOTTO x MANDRINO DA RIPRESA AS/GS20 PNEUMATICO
1518105	RING A CROSS for COUPLING front spindle AS/GS/GM20 IT: ANELLO A CROCE x GIUNTO MANDRINO FRONTALE AS/GS/GM20
4801605	RING Ø 23 for pick-up spindle IT: ANELLO Ø 23 x MANDRINO DA RIPRESA
1558132	ROD THREADED for pick-up spindle IT: ASTA FILETTATA x MANDRINO DA RIPRESA
0853019	ROLLER for STOP SPINDLE IT: RULLO x ARRESTO MANDRINO
1909105	SCREW for CLAMPING SPINDLES P.POINT IT: VITE x BLOCCAGGIO MANDRINI P.PUNTA
0801402	SCREW for COMPENSATOR ADJUSTMENT COLLET GILD.AS16 AS/GS/GM20 IT: VITE x COMPENSATORE REGISTRAZIONE PINZA GILD.AS16 AS/GS/GM20
0514014	SCREW for REST LEVER front spindles IT: VITE x APPOGGIO LEVA MANDRINI FRONTALI
1402001	SECTOR for OPENING COLLET IT: SETTORE x APERTURA PINZA
0801350	SET BELL HOUSING+BEARING open/close. COLLET GILD.AS16-AS/GS/GM20 IT: SET CAMPANA+CUSCINETTO A/C. PINZA GILD.AS16-AS/GS/GM20
3155109	SLEEVE SPECIAL for front spindle GILD.AS/GS/GM20 IT: MANICOTTO SPECIALE x MANDRINO FRONTALE GILD.AS/GS/GM20

2801502	SLEEVE collet holder GILD.GS20 FAST IT: BICCHIERE PORTAPINZA GILD.GS20 VELOCE
0807011	SLEEVE for front spindle GILD.AS/GS/GM20 IT: MANICOTTO x MANDRINO FRONTALE GILD.AS/GS/GM20
0814005	SLEEVE for front spindles IT: MANICOTTO x MANDRINI FRONTALI
3113126	SMALL CASING MICRO RETURN front spindles GILD. AS-GS-GM20 IT: CARTERINO MICRO RITORNO MANDRINI FRONTALI GILD. AS-GS-GM20
1522001S	SMALL COLUMN LEVERS front spindles GILD.AS/GS20 Ø20 SPECIAL LL=485 IT: COLONNINA LEVE MANDRINI FRONTALI GILD.AS/GS20 Ø20 SPECIALE LL=485
1522001	SMALL COLUMN for LEVERS front spindles GILD. AS/GS20 Ø 20 IT: COLONNINA x LEVE MANDRINI FRONTALI GILD. AS/GS20 Ø 20
3122116	SMALL COLUMN for LEVERS front spindles GILD. GM20 Ø24 IT: COLONNINA x LEVE MANDRINI FRONTALI GILD. GM20 Ø24
20096301	SMALL LEVER FOR open/close COLLET CLOSURE REINFORCED GILD.AS16/20 (10.0632) IT: LEVETTA PER A/C PINZA CHIUSURA RINFORZATA GILD.AS16/20 (10.0632)
20096301E	SMALL LEVER FOR open/close COLLET CLOSURE REINFORCED GILD.AS16/20 (10.0632E) IT: LEVETTA PER A/C PINZA CHIUSURA RINFORZATA GILD.AS16/20 (10.0632E)
0801303	SMALL LEVER FOR open/close COLLET GILD. AS16/20 (10.0601) IT: LEVETTA PER A/C PINZA GILD. AS16/20 (10.0601)
0801303E	SMALL LEVER FOR open/close COLLET GILD. AS16/20 (10.0601E) IT: LEVETTA PER A/C PINZA GILD. AS16/20 (10.0601E)
100624	SMALL LEVER FOR open/close COLLET GILD. GLD 20/25 (54.10.119-54.10.254) IT: LEVETTA PER A/C PINZA GILD. GLD 20/25 (54.10.119-54.10.254)
3101108E	SMALL LEVER FOR open/close COLLET GILD. GS/GM20 (10.0626E) IT: LEVETTA PER A/C PINZA GILD. GS/GM20 (10.0626E)
3101108	SMALL LEVER open/close COLLET GILD. GS/GM20 (10.0626) IT: LEVETTA A/C PINZA GILD. GS/GM20 (10.0626)
3125112	SMALL SUPPORT for front spindles GILD. AS/GS/GM20 BORED (15.25.205 / 15.25.304) IT: SUPPORTINO x MANDRINI FRONTALI GILD. AS/GS/GM20 BARENATO (15.25.205 / 15.25.304)
3125113	SMALL SUPPORT for front spindles GILD. AS/GS/GM20 SEMI-FINISHED (WITHOUT BRONZE BUSHINGS) IT: SUPPORTINO x MANDRINI FRONTALI GILD. AS/GS/GM20 SEMILAVORATO (SENZA BRONZINE)
0513013	SPACER CONTROL ROTATION front spindles GILD.20 IT: DISTANZIALE COMANDO ROTAZIONE MANDRINI FRONTALI GILD.20
1558103	SPACER EXT.. for pick-up spindle PNEUMATIC (31.58.146) IT: DISTANZIALE EST. x MANDRINO DA RIPRESA PNEUMATICO (31.58.146)
1501604	SPACER for DRAW ROD BAR PUSHER VARIANT 25mm IT: DISTANZIALE x TIRANTE SPINGIBARRA VARIANTE 25mm
3160106	SPACER for STOP SPINDLES bar guides IT: DISTANZIALE x ARRESTO MANDRINI PORTABARRE
0801101	SPINDLE IT: MANDRINO
2723026	SPINDLE IT: MANDRINO
3126146	SPINDLE IT: MANDRINO
3126146ER32	SPINDLE IT: MANDRINO
3126146ER32L	SPINDLE IT: MANDRINO
4526116L	SPINDLE IT: MANDRINO
4526284	SPINDLE IT: MANDRINO
3101109	SPINDLE GILD.GS/GM20 IT: MANDRINO GILD.GS/GM20

0847028	SPINDLE LONG for PICK-UP AS16 IT: MANDRINO LUNGO x PICK-UP AS16
1558146	SPINDLE PICK-UP IT: MANDRINO PICK-UP
1558113	SPINDLE SPLINED PICK-UP IT: MANDRINO SCANALATO PICK-UP
1103002	SPINDLE STUB for front spindle GM20 IT: FUSO x MANDRINO FRONTALE GM20
3126146 L	SPINDLE WITH ROD PLAIN IT: MANDRINO CON STELO LISCIO
0847000M	SPINDLE for AS16 IT: MANDRINO x AS16
2802205	SPRING A CUP for COUPLING front spindles GILD. GS20 FAST IT: MOLLA A TAZZA x GIUNTO MANDRINI FRONTALI GILD. GS20 VELOCE
1518205	SPRING A CUP for COUPLING front spindles GILD.AS/GS/GM20 IT: MOLLA A TAZZA x GIUNTO MANDRINI FRONTALI GILD.AS/GS/GM20
0840019	SPRING A TRACTION FOR front spindle GILD.AS/GS/GM20 IT: MOLLA A TRAZIONE PER MANDRINO FRONTALE GILD.AS/GS/GM20
0840019R	SPRING A TRACTION REINFORCED (F=2mm) for front spindles GILD.AS/GS/GM20 IT: MOLLA A TRAZIONE RINFORZATA (F=2mm) x MANDRINI FRONTALI GILD.AS/GS/GM20
0501005	SPRING for COMPENSATOR ADJUSTMENT COLLET GILD.AS16 AS/GS/GM20 IT: MOLLA x COMPENSATORE REGISTRAZIONE PINZA GILD.AS16 AS/GS/GM20
0517020	SPRING for OVERLOAD L.H. (open/close. COLLET) IT: MOLLA x SOVRACCARICO SX (A/C. PINZA)
0513036	SPRING for RETURN front spindles (FOR THREADING F=2.5) IT: MOLLA x RITORNO MANDRINI FRONTALI (PER FILETTATURA F=2.5)
0513035	SPRING for RETURN front spindles (FOR THREADING F=2.8) IT: MOLLA x RITORNO MANDRINI FRONTALI (PER FILETTATURA F=2.8)
0513038	SPRING for RETURN front spindles (STANDARD F=3) IT: MOLLA x RITORNO MANDRINI FRONTALI (STANDARD F=3)
4526103	STOP POSITIVE for front spindle FIXED IT: FERMO POSITIVO x MANDRINO FRONTALE FISSO
1526005	STOP POSITIVE for front spindle ROTATING IT: FERMO POSITIVO x MANDRINO FRONTALE ROTANTE
0840200	SYNCHRONOUS for pick-up spindle AS16 IT: SINCRONO x MANDRINO DA RIPRESA AS16
3160189	WHEEL Z=30 for POSITIONING SPINDLE IT: RUOTA Z=30 x POSIZIONAMENTO MANDRINO
3124121	WRENCH FOR COLLAR NUT SPINDLE GILD.20 IT: CHIAVE PER GHIERA MANDRINO GILD.20
3124121M	WRENCH FOR COLLAR NUT SPINDLE GILD.20 (SPECIAL WITH SQUARE) IT: CHIAVE PER GHIERA MANDRINO GILD.20 (SPECIALE CON QUADRO)
0847302	WRENCH FOR COLLET pick-up spindle PNEUMATIC IT: CHIAVE PER PINZA MANDRINO DA RIPRESA PNEUMATICO
1524202	WRENCH OF EXTRACTION for front spindle GILD.AS/GS/GM20 IT: CHIAVE DI ESTRAZIONE x MANDRINO FRONTALE GILD.AS/GS/GM20
1524205	WRENCH for COUNTER-COLLETS GILD.AS/GS/GM20 V.25mm IT: CHIAVE x CONTROPINZE GILD.AS/GS/GM20 V.25mm
1558201	WRENCH for pick-up spindle GILD.AS16/20 PNEUMATIC IT: CHIAVE x MANDRINO DA RIPRESA GILD.AS16/20 PNEUMATICO
3120101	cam carrier shaft for front spindles GILD.AS/GS/GM20 IT: ALBERO PORTA CAMME x MANDRINI FRONTALI GILD.AS/GS/GM20
3120101TF	cam carrier shaft for front spindles GILD.AS/GS/GM20 SPECIAL (Ø35 h5) IT: ALBERO PORTA CAMME x MANDRINI FRONTALI GILD.AS/GS/GM20 SPECIALE (Ø35 h5)
0817004	cam carrier shaft for front spindles GILD.AS16 IT: ALBERO PORTA CAMME x MANDRINI FRONTALI GILD.AS16

1501603	collet sleeve GILD.AS/GS/GM20 VARIANT 25mm IT: BICCHIERE P.PINZA GILD.AS/GS/GM20 VARIANTE 25mm
1401251	collet sleeve GILD.AS16-AS/GS/GM20 IT: BICCHIERE P.PINZA GILD.AS16-AS/GS/GM20
1526101L	front spindle FIXED WITH ROD PLAIN for GILD.AS/GS/GM20 IT: MANDRINO FRONTALE FISSO CON STELO LISCIO x GILD.AS/GS/GM20
1526101ER32L	front spindle FIXED WITH ROD PLAIN for GILD.AS/GS/GM20 ER32 IT: MANDRINO FRONTALE FISSO CON STELO LISCIO x GILD.AS/GS/GM20 ER32
4526115L	front spindle FIXED WITH ROD PLAIN for GILD.AS/GS/GM20 ISO30 IT: MANDRINO FRONTALE FISSO CON STELO LISCIO x GILD.AS/GS/GM20 ISO30
4526017	front spindle FIXED WITH ROD PLAIN for GILD.AS/GS/GM20 ISO30 R.I.G. IT: MANDRINO FRONTALE FISSO CON STELO LISCIO x GILD.AS/GS/GM20 ISO30 R.I.G.
1526101	front spindle FIXED for GILD.AS/GS/GM20 IT: MANDRINO FRONTALE FISSO x GILD.AS/GS/GM20
1526101ER32	front spindle FIXED for GILD.AS/GS/GM20 ER32 IT: MANDRINO FRONTALE FISSO x GILD.AS/GS/GM20 ER32
0814013	front spindle GILD.AS16 IT: MANDRINO FRONTALE GILD.AS16
1526001L	front spindle ROTATING WITH ROD PLAIN for GILD. AS-GS-GM20 COLLET GITAL (Complete of Collar nut) IT: MANDRINO FRONTALE ROTANTE CON STELO LISCIO x GILD. AS-GS-GM20 PINZA GITAL (Completo di Ghiera)
1526001ER32L	front spindle ROTATING WITH ROD PLAIN for GILD.AS/GS/GM20 ER32 IT: MANDRINO FRONTALE ROTANTE CON STELO LISCIO x GILD.AS/GS/GM20 ER32
4526015	front spindle ROTATING WITH ROD PLAIN for GILD.AS/GS/GM20 ISO30 R.I.G. L=175 IT: MANDRINO FRONTALE ROTANTE CON STELO LISCIO x GILD.AS/GS/GM20 ISO30 R.I.G. L=175
1526001	front spindle ROTATING for GILD. AS-GS-GM20 COLLET GITAL (Complete of Collar nut) IT: MANDRINO FRONTALE ROTANTE x GILD. AS-GS-GM20 PINZA GITAL (Completo di Ghiera)
1526001ER32	front spindle ROTATING for GILD. AS-GS-GM20 ER32 (Complete of Collar nut) IT: MANDRINO FRONTALE ROTANTE x GILD. AS-GS-GM20 ER32 (Completo di Ghiera)
4526055	front spindle ROTATING for GILD.AS/GS/GM20 R.I.L ISO 30 Z.L IT: MANDRINO FRONTALE ROTANTE x GILD.AS/GS/GM20 R.I.L ISO 30 Z.L
1518001	front spindle SPLINED for GILD.AS/GS/GM20 IT: MANDRINO FRONTALE SCANALATO x GILD.AS/GS/GM20

Bar Feed & Guide		81
3113239S	ANGLE BRACKET MICRO BAR STOP POS. 3 GILD. GM20 IT: SQUADRA MICRO FERMOBARRA POS. 3 GILD. GM20	
3113243	ANGLE BRACKET micrometer holder for CONTROL END BAR POS.1 IT: SQUADRA PORTAMICRO x CONTROLLO FINE BARRA POS.1	
0826101	ANGLE BRACKET micrometer holder for CONTROL END BAR POS.6 (31.13.107 / 31.13.251 / 45.03.102) IT: SQUADRA PORTAMICRO x CONTROLLO FINE BARRA POS.6 (31.13.107 / 31.13.251 / 45.03.102)	
1519001	ARM STOP BAR (feed. 0/60mm) GILD.AS16/20 IT: BRACCIO FERMO BARRA (avanz. 0/60mm) GILD.AS16/20	
0519001	ARM STOP BAR (feed. 0/60mm) IMIS16/GILD.AS16 (AS16 only first mod.) IT: BRACCIO FERMO BARRA (avanz. 0/60mm) IMIS16/GILD.AS16 (AS16 solo primi mod.)	
1519002	ARM STOP BAR (feed. 60/100mm) GILD.AS16/20 IT: BRACCIO FERMO BARRA (avanz. 60/100mm) GILD.AS16/20	
0803014	BUSHING for ASSEMBLY FEED BAR IT: BOCCOLA x GRUPPO AVANZAMENTO BARRA	
0803015	BUSHING for ASSEMBLY FEED BAR IT: BOCCOLA x GRUPPO AVANZAMENTO BARRA	
1529159	CAM FEED BAR IT: CAMMA AVANZAMENTO BARRA	
3119102	CONNECTING ROD for STOP BAR GILD.GS/GM20 IT: BIELLA x FERMO BARRA GILD.GS/GM20	

3119122	CONNECTING ROD for STOP BAR GILD.GS/GM20 IT: BIELLA x FERMO BARRA GILD.GS/GM20
0869103	COVER HOUSING CONVEYOR GILD.AS16/20 IT: COPERCHIO SCATOLA CONVOGLIATORE GILD.AS16/20
1662552	FEELER for CONTROL END BAR POS.1 IT: TASTATORE x CONTROLLO FINE BARRA POS.1
0826102	FEELER for CONTROL END BAR POS.6 IT: TASTATORE x CONTROLLO FINE BARRA POS.6
3112137	FLANGE IN ALUMINUM X bar guides GILD.20 IT: FLANGIA IN ALLUMINIO X PORTABARRE GILD.20
1512151 CM	FLANGE for TUBE bar guide IT: FLANGIA x TUBO PORTABARRA
1403002	HANDLE for RING FEED BAR (07.93.07) IT: MANIGLIA x ANELLO AVANZAMENTO BARRA (07.93.07)
1623104	HOUSING CONVEYOR GILD.AS16/20 IT: SCATOLA CONVOGLIATORE GILD.AS16/20
0834052	INSERT M12 for CLAMPING CARRIER SMALL BAR GILD.AS/GS/GM20 IT: TASSELLO M12 x BLOCCAGGIO PORTA BARRETTA GILD.AS/GS/GM20
3119117	LEVER STOP BAR GILD.GM20 FOR BAR UP TO A 100mm (03.96.55) IT: LEVA FERMO BARRA GILD.GM20 PER BARRA FINO A 100mm (03.96.55)
1519012	LEVER for STOP BAR IT: LEVA x FERMO BARRA
1519024	PAD IN WIDIA for BAR STOP GILD.AS/GS/GM20 IT: PASTICCA IN WIDIA x FERMOBARRA GILD.AS/GS/GM20
1519024 29	PAD IN WIDIA for BAR STOP GILD.AS16-AS/GS/GM20 OVERSIZED Ø 29 IT: PASTICCA IN WIDIA x FERMOBARRA GILD.AS16-AS/GS/GM20 MAGGIORATA Ø 29
0117013	PIN CONVEYOR IT: PERNO CONVOGLIATORE
0801504	PIN SUPPORT ENGAGEMENT bar guide GILD.GS/GM20-GM32/35/42 IT: PERNO SUPPORTO INNESTO PORTABARRA GILD.GS/GM20-GM32/35/42
1403003	PIN for FEED BAR IT: PERNO x AVANZAMENTO BARRA
0503010	PIN for LEVER FEED BAR IT: PERNO x LEVA AVANZAMENTO BARRA
1419002	PIN for LEVER STOP BAR AS16 (L=255) IT: PERNO x LEVA FERMO BARRA AS16 (L=255)
1519017	PIN for LEVER STOP BAR GILD.AS16-20 IT: PERNO x LEVA FERMO BARRA GILD.AS16-20
3119127	PIN for LEVER STOP BAR GM20 IT: PERNO x LEVA FERMO BARRA GM20
1305127	PIN for STOP BAR IT: PERNO x FERMO BARRA
0519014	PIN for STOP BAR GILD.AS16 IT: PERNO x FERMO BARRA GILD.AS16
3119103	PIN for STOP BAR GILD.GS/GM20 IT: PERNO x FERMO BARRA GILD.GS/GM20
3119104	PIN for STOP BAR GILD.GS/GM20 IT: PERNO x FERMO BARRA GILD.GS/GM20
3113239	PLATE CARRIER MICRO STOP BAR IT: PIASTRA PORTA MICRO FERMO BARRA
3113234	PLATE STOP BAR IT: PIASTRA FERMO BARRA
0803003	PLUG for HANDLE FEED BAR IT: TAPPO x MANIGLIA AVANZAMENTO BARRA
0106612	ROLLER for FEED BAR IT: RULLO x AVANZAMENTO BARRA

0107247	ROLLER for STOP BAR GILD.AS/GS/GM20 / ROLLING IT: RULLO x FERMO BARRA GILD.AS/GS/GM20 / RULLATURA
0207016	ROLLER for STOP BAR GILD.AS16 IT: RULLO x FERMO BARRA GILD.AS16
3101101	SCREW bar guides GILD.GS/GM20-GM35 IT: VITE PORTABARRE GILD.GS/GM20-GM35
1403001	SCREW for HANDLE FEED BAR IT: VITE x MANIGLIA AVANZAMENTO BARRA
1519011	SCREW for STOP BAR IT: VITE x FERMO BARRA
3119124	SCREW for STOP BAR GM20 IT: VITE x FERMO BARRA GM20
3119109	SCREW for STOP BAR GS20 IT: VITE x FERMO BARRA GS20
1503001	SECTOR for FEED BAR IT: SETTORE x AVANZAMENTO BARRA
1560303	SECTOR for FEED BAR IT: SETTORE x AVANZAMENTO BARRA
1560304	SECTOR for FEED BAR IT: SETTORE x AVANZAMENTO BARRA
1560305	SECTOR for FEED BAR IT: SETTORE x AVANZAMENTO BARRA
1623106	SHAFT CONVEYOR CHIPS IT: ALBERO CONVOGLIATORE TRUCIOLI
1623105	SHAFT CONVEYOR CHIPS (BEARING Ø17) IT: ALBERO CONVOGLIATORE TRUCIOLI (CUSCINETTO Ø17)
1519004	SHAFT for STOP BAR GILD.AS16/20 IT: ALBERO x FERMO BARRA GILD.AS16/20
3119121	SHAFT for STOP BAR GILD.GM20 IT: ALBERO x FERMO BARRA GILD.GM20
3119101	SHAFT for STOP BAR GILD.GS/GM20 IT: ALBERO x FERMO BARRA GILD.GS/GM20
0801017	SLIDE SHOE IN BRONZE for FEED BAR GILD.AS/GS/GM20 IT: PATTINO IN BRONZO x AVANZAMENTO BARRA GILD.AS/GS/GM20
1519014	SLIDE SHOE for LEVER STOP BAR GILD.AS20 IT: PATTINO x LEVA FERMO BARRA GILD.AS20
0826103	SMALL PEG CONTROL END BAR GILD.GM20/35 IT: PIOLINO CONTROLLO FINE BARRA GILD.GM20/35
0106606	SMALL WASHER for FEED BAR IT: ROSETTA x AVANZAMENTO BARRA
1551452	SPACER STUB SHAFT CONVEYOR GILD.AS16/20 IT: DISTANZIALE ALBERINO CONVOGLIATORE GILD.AS16/20
0826104	SPRING CONTROL END BAR GILD.GM20/35 IT: MOLLA CONTROLLO FINE BARRA GILD.GM20/35
1003006	SPRING FEED BAR GILD.20 IT: MOLLA AVANZAMENTO BARRA GILD.20
1551305	SPRING OVERLOAD CONVEYOR IT: MOLLA SOVRACCARICO CONVOGLIATORE
0520010	SPRING SUPPORT ENGAGEMENT bar guide GILD.GS/GM20-GM32/35/42 IT: MOLLA SUPPORTO INNESTO PORTABARRA GILD.GS/GM20-GM32/35/42
0802004	SPRING SUPPORT ENGAGEMENT bar guide GILD.GS/GM20-GM32/35/42 IT: MOLLA SUPPORTO INNESTO PORTABARRA GILD.GS/GM20-GM32/35/42
0520305	SPRING SUPPORT ENGAGEMENT bar guides GILD.GM16/20/35 IT: MOLLA SUPPORTO INNESTO PORTABARRE GILD.GM16/20/35
0918003	SPRING TENSIONER STOP BAR GILD.GM16/20/35 IT: TENDIMOLLA FERMO BARRA GILD.GM16/20/35

0818010	SPRING X BUNDLE TUBE GUIDE GILD.AS/GS/GM20 (BAR D.0-7) IT: MOLLA X FASCIO TUBIERO GILD.AS/GS/GM20 (BARRA D.0-7)
0818007	SPRING X BUNDLE TUBE GUIDE GILD.AS/GS/GM20 (BAR D.16-20) IT: MOLLA X FASCIO TUBIERO GILD.AS/GS/GM20 (BARRA D.16-20)
0818008	SPRING for BUNDLE TUBE GUIDE GILD.AS/GS/GM20 (BAR D.12-16) IT: MOLLA x FASCIO TUBIERO GILD.AS/GS/GM20 (BARRA D.12-16)
1512001	SPRING for BUNDLE TUBE GUIDE GILD.AS/GS/GM20 (BAR D.20-25) IT: MOLLA x FASCIO TUBIERO GILD.AS/GS/GM20 (BARRA D.20-25)
0818009	SPRING for BUNDLE TUBE GUIDE GILD.AS/GS/GM20 (BAR D.7-12) IT: MOLLA x FASCIO TUBIERO GILD.AS/GS/GM20 (BARRA D.7-12)
1519022	SPRING for STOP BAR IT: MOLLA x FERMO BARRA
3119111	SPRING for STOP BAR GILD.GM20 IT: MOLLA x FERMO BARRA GILD.GM20
1547259	STOP UNLOADED for SUPPORT ENGAGEMENT bar guide IT: FERMO SCARICATO x SUPPORTO INNESTO PORTABARRA
1551453	STUB SHAFT CONVEYOR GILD.20 IT: ALBERINO CONVOGLIATORE GILD.20
1502051	SUPPORT for FEED BAR GILD.AS/GS/GM20 (08.03.001) IT: SUPPORTO x AVANZAMENTO BARRA GILD.AS/GS/GM20 (08.03.001)
0818103/2900	TUBE bar guide for BUNDLE TUBE GUIDE GILD.AS/GS/GM20 LL=2900 IT: TUBO PORTABARRA x FASCIO TUBIERO GILD.AS/GS/GM20 LL=2900
0818103/3400	TUBE bar guide for BUNDLE TUBE GUIDE GILD.AS/GS/GM20 LL=3400 IT: TUBO PORTABARRA x FASCIO TUBIERO GILD.AS/GS/GM20 LL=3400
0818103/3600	TUBE bar guide for BUNDLE TUBE GUIDE GILD.AS/GS/GM20 LL=3600 IT: TUBO PORTABARRA x FASCIO TUBIERO GILD.AS/GS/GM20 LL=3600
1017406	WHEEL X CONVEYOR Z=30 IT: RUOTA X CONVOGLIATORE Z=30
1017403	WHEEL for CONVEYOR Z=22 IT: RUOTA x CONVOGLIATORE Z=22

Tool Heads & Tooling		48
3142101	ARM P.TOOL FOR PICK-UP OSCILLATING POS. 6 GILD.GM20 IT: BRACCIO P.UTENSILE DA RIPRESA OSCILLANTE POS. 6 GILD.GM20	
3142102	BLOCK center holder Ø10 for P.TOOL FOR PICK-UP OSCILLATING GILD.GM20 IT: BLOCCHETTO PORTAPUNTA Ø10 x P.UTENSILE DA RIPRESA OSCILLANTE GILD.GM20	
0513021	BUSHING SPLINED for SHAFT THREADING HEAD AS/GS/GM20 IT: BOCCOLA SCANALATA x ALBERO FILETTATORE AS/GS/GM20	
3158139	BUSHING for EJECTOR ROTATING (CH.15) IT: BOCCOLA x ESPULSORE ROTANTE (CH.15)	
3158139F	BUSHING for EJECTOR ROTATING THREADED (M.18for1) IT: BOCCOLA x ESPULSORE ROTANTE FILETTATA (M.18x1)	
1558139/6	BUSHING for ROD EJECTOR Ø6 (15.58.252) IT: BOCCOLA x ASTA ESPULSORE Ø6 (15.58.252)	
1558139/8	BUSHING for ROD EJECTOR Ø8 IT: BOCCOLA x ASTA ESPULSORE Ø8	
3158272	EJECTOR SEMI-FINISHED for PICK-UP PNEUMATIC IT: ESPULSORE SEMILAVORATO x PICK-UP PNEUMATICO	
1049206	EJECTOR SEMI-FINISHED for PICK-UP PNEUMATIC WITH RODS Ø 6 IT: ESPULSORE SEMILAVORATO x PICK-UP PNEUMATICO CON ASTE Ø 6	
0825660	GAUGE LEFT HEIGHT TOOL GILD.20 POS.1-2-4-5 H=30 IT: CALIBRO SINISTRO ALTEZZA UTENSILE GILD.20 POS.1-2-4-5 H=30	
0825650	GAUGE RIGHT HEIGHT TOOL GILD.20 POS.1-2-4-5 H=30 IT: CALIBRO DESTRO ALTEZZA UTENSILE GILD.20 POS.1-2-4-5 H=30	

0825150	GAUGE STRAIGHT HEIGHT TOOL GILD.20 POS.1-2-4-5 H=30 IT: CALIBRO DRITTO ALTEZZA UTENSILE GILD.20 POS.1-2-4-5 H=30
0825200	GAUGE STRAIGHT HEIGHT TOOL GILD.20 POS.3-6 H=60 IT: CALIBRO DRITTO ALTEZZA UTENSILE GILD.20 POS.3-6 H=60
0834054	INSERT M8 for PLATE tool holder POS.3 GILD.AS16-20/GS20 IT: TASSELLO M8 x PIASTRA PORTA UTENSILE POS.3 GILD.AS16-20/GS20
0834802	KEY for TURRET MODULAR REDUCED for GILD. AS16-20/GS20 IT: CHIAVETTA x TORRETTA MODULARE RIDOTTA x GILD. AS16-20/GS20
0834053	KEY for TURRET MODULAR STANDARD for GILD. AS16-20/GS20 IT: CHIAVETTA x TORRETTA MODULARE STANDARD x GILD. AS16-20/GS20
0834055	KEY/INSERT for PLATE tool holder POS.3 GILD. AS16-20/GS20 IT: CHIAVETTA/TASSELLO x PIASTRA PORTA UTENSILE POS.3 GILD. AS16-20/GS20
0834803	KEY/INSERT for PLATE tool holder POS.3 GILD. AS16-20/GS20 IT: CHIAVETTA/TASSELLO x PIASTRA PORTA UTENSILE POS.3 GILD. AS16-20/GS20
3158271	NUT M8 for EJECTOR ROTATING IT: DADO M8 x ESPULSORE ROTANTE
0834351	P.TOOL PRISMATIC IT: P.UTENSILE PRISMATICO
3658125	ROD EJECTOR IT: ASTA ESPULSORE
1558251 773	ROD EJECTOR VARIABLE PICK-UP PNEUMATIC AS/GS/GM20 Ø6 A=773 IT: ASTA ESPULSORE VARIABILE PICK-UP PNEUMATICO AS/GS/GM20 Ø6 A=773
1558251 813	ROD EJECTOR VARIABLE PICK-UP PNEUMATIC AS/GS/GM20 Ø6 A=813 IT: ASTA ESPULSORE VARIABILE PICK-UP PNEUMATICO AS/GS/GM20 Ø6 A=813
1558251 853	ROD EJECTOR VARIABLE PICK-UP PNEUMATIC AS/GS/GM20 Ø6 A=853 (31.58.220) IT: ASTA ESPULSORE VARIABILE PICK-UP PNEUMATICO AS/GS/GM20 Ø6 A=853 (31.58.220)
3158267	ROD EJECTOR VARIABLE for GILD.GM20 Ø8 L=765 IT: ASTA ESPULSORE VARIABILE x GILD.GM20 Ø8 L=765
3158268	ROD EJECTOR VARIABLE for GILD.GM20 Ø8 L=780 IT: ASTA ESPULSORE VARIABILE x GILD.GM20 Ø8 L=780
3158269	ROD EJECTOR VARIABLE for GILD.GM20 Ø8 L=820 IT: ASTA ESPULSORE VARIABILE x GILD.GM20 Ø8 L=820
3158275	ROD EJECTOR VARIABLE for GILD.GM20 Ø8 L=860 IT: ASTA ESPULSORE VARIABILE x GILD.GM20 Ø8 L=860
0810005	SHAFT for THREADING HEAD IT: ALBERO x FILETTATORE
1745402	SMALL HEAD EJECTOR IT: TESTINA ESPULSORE
3158270	STOP for EJECTOR ROTATING IT: FERMO x ESPULSORE ROTANTE
0518049	SUPPORT for THREADING HEAD AS20 IT: SUPPORTO x FILETTATORE AS20
3117117	SUPPORT for THREADING HEAD GM20 IT: SUPPORTO x FILETTATORE GM20
1517403	SUPPORT for THREADING HEAD GS20 IT: SUPPORTO x FILETTATORE GS20
0814015	TUBE for THREADING HEAD WITH SLOT 12mm IT: TUBO x FILETTATORE CON CAVA 12mm
1518006	TUBE for THREADING HEAD WITH SLOT 20mm IT: TUBO x FILETTATORE CON CAVA 20mm
1517017	TUBE for THREADING HEAD WITH TOOTH 20 mm IT: TUBO x FILETTATORE CON DENTE 20 mm
0810039	TUBE for THREADING HEAD WITH TOOTH FOR 12mm IT: TUBO x FILETTATORE CON DENTE DA 12mm
06050801	TURRET IT: TORRETTA

0834051	TURRET GR1 FOR AS-GS-GM20 <i>IT: TORRETTA GR1 PER AS-GS-GM20</i>
0834901	TURRET GR1 SPECIAL POS.1 FOR AS-GS-GM20 <i>IT: TORRETTA GR1 SPECIALE POS.1 PER AS-GS-GM20</i>
0834801	TURRET SPECIAL REDUCED for AS-GS-GM20 <i>IT: TORRETTA SPECIALE RIDOTTA x AS-GS-GM20</i>
06051101	tool holder <i>IT: PORTAUTENSILE</i>
0834851	tool holder <i>IT: PORTAUTENSILE</i>
0834301	tool holder 14for14 (06001601) <i>IT: PORTAUTENSILE 14x14 (06001601)</i>
0834301H16	tool holder H=16 <i>IT: PORTAUTENSILE H=16</i>
0834301H18	tool holder H=18 <i>IT: PORTAUTENSILE H=18</i>
0834501	tool holder PRISMATIC <i>IT: PORTAUTENSILE PRISMATICO</i>

Mechanical Transmission		178
2001D349	BELT MOTOR 50HZ for GILD.GM20 (10.31.63) IT: CINGHIA MOTORE 50HZ x GILD.GM20 (10.31.63)	
2001D347	BELT MOTOR 60HZ for GILD.GM20 (10.31.61) IT: CINGHIA MOTORE 60HZ x GILD.GM20 (10.31.61)	
2001D348	BELT MOTOR AC for GILD.GM20 (10.31.62) 1082 IT: CINGHIA MOTORE AC x GILD.GM20 (10.31.62) 1082	
2001D346	BELT MOTOR for GILD.AS16/20 GS20 (10.30.97) IT: CINGHIA MOTORE x GILD.AS16/20 GS20 (10.30.97)	
1551303	BUSHING for COUPLING OVERLOAD IT: BOCCOLA x GIUNTO SOVRACCARICO	
1694250	CAM IT: CAMMA	
1694639	CAM IT: CAMMA	
0829303	CAM LATCH for GILD.AS/GS/GM20 IT: CAMMA CHIAVISTELLO x GILD.AS/GS/GM20	
0525660	CONNECTING ROD IT: BIELLA	
0853304	CONNECTING ROD IT: BIELLA	
1521104	CONNECTING ROD IT: BIELLA	
1521303	CONNECTING ROD IT: BIELLA	
3158285	CONNECTING ROD IT: BIELLA	
0508025	CONNECTING ROD (05.09.402) IT: BIELLA (05.09.402)	
0106609 M	CONNECTING ROD (M) L=273mm IT: BIELLA (M) L=273mm	
0853203A92	CONNECTING ROD A=92mm IT: BIELLA A=92mm	
0853203A93	CONNECTING ROD A=93mm IT: BIELLA A=93mm	

0853203A94	CONNECTING ROD A=94mm IT: BIELLA A=94mm
0853203A95	CONNECTING ROD A=95mm IT: BIELLA A=95mm
0853203A96	CONNECTING ROD A=96mm IT: BIELLA A=96mm
1550900	CONNECTING ROD COMPENSATED for GILD.AS/GS/GM20 IT: BIELLA COMPENSATA x GILD.AS/GS/GM20
0106609	CONNECTING ROD L=293mm IT: BIELLA L=293mm
1527004	CONNECTING ROD for LEVER CONTROL SUPPORT CENTRAL IT: BIELLA x LEVA COMANDO SUPPORTO CENTRALE
3118020	COUPLING IT: GIUNTO
0815001	COUPLING for SCREW WITHOUT END GILD.AS/GS/GM20 IT: GIUNTO x VITE SENZA FINE GILD.AS/GS/GM20
0810049	ELECTRIC CLUTCH FEEDS GR.15 for GILD.AS/GS/GM20 ORIGINAL ORTLINGHAUS IT: ELETTROFRIZIONE AVANZAMENTI GR.15 x GILD.AS/GS/GM20 ORIGINALE ORTLINGHAUS
0810203	ELECTRIC CLUTCH THREADING GR.23 for GILD.AS16-AS/GS/GM20 ORIGINAL ORTLINGHAUS (3665307) IT: ELETTROFRIZIONE FILETTATURA GR.23 x GILD.AS16-AS/GS/GM20 ORIGINALE ORTLINGHAUS (3665307)
0810038	FLANGE CONTROL ROTATION DRUM E SHAFTS P.CAMS GILD.20 IT: FLANGIA COMANDO ROTAZIONE TAMBURO E ALBERI P.CAMME GILD.20
0810011	GEAR IT: INGRANAGGIO
0852005	GEAR IT: INGRANAGGIO
0801005	GEAR CENTRAL IT: INGRANAGGIO CENTRALE
0810500 Z19	GEAR PRODUCTION Z=19 (08.10.501) IT: INGRANAGGIO PRODUZIONE Z=19 (08.10.501)
0810500 Z20	GEAR PRODUCTION Z=20 (08.10.502) IT: INGRANAGGIO PRODUZIONE Z=20 (08.10.502)
0810500 Z23	GEAR PRODUCTION Z=23 (08.10.503) IT: INGRANAGGIO PRODUZIONE Z=23 (08.10.503)
0810500 Z26	GEAR PRODUCTION Z=26 (08.10.504) IT: INGRANAGGIO PRODUZIONE Z=26 (08.10.504)
0810500 Z29	GEAR PRODUCTION Z=29 (08.10.505) IT: INGRANAGGIO PRODUZIONE Z=29 (08.10.505)
0810500 Z32	GEAR PRODUCTION Z=32 (08.10.506) IT: INGRANAGGIO PRODUZIONE Z=32 (08.10.506)
0810500 Z41	GEAR PRODUCTION Z=41 (08.10.507) IT: INGRANAGGIO PRODUZIONE Z=41 (08.10.507)
0810500 Z49	GEAR PRODUCTION Z=49 (08.10.508) IT: INGRANAGGIO PRODUZIONE Z=49 (08.10.508)
0810500 Z58	GEAR PRODUCTION Z=58 (08.10.509) IT: INGRANAGGIO PRODUZIONE Z=58 (08.10.509)
0810500 Z61	GEAR PRODUCTION Z=61 (08.10.510) IT: INGRANAGGIO PRODUZIONE Z=61 (08.10.510)
0810500 Z64	GEAR PRODUCTION Z=64 (08.10.511) IT: INGRANAGGIO PRODUZIONE Z=64 (08.10.511)
0810500 Z67	GEAR PRODUCTION Z=67 (08.10.512) IT: INGRANAGGIO PRODUZIONE Z=67 (08.10.512)
0810500 Z70	GEAR PRODUCTION Z=70 (08.10.513) IT: INGRANAGGIO PRODUZIONE Z=70 (08.10.513)
0810500 Z71	GEAR PRODUCTION Z=71 (08.10.514) IT: INGRANAGGIO PRODUZIONE Z=71 (08.10.514)

0810400 Z27	GEAR REVOLUTIONS Z=27 (08.10.401) IT: INGRANAGGIO GIRI Z=27 (08.10.401)
0810400 Z29	GEAR REVOLUTIONS Z=29 (08.10.402) IT: INGRANAGGIO GIRI Z=29 (08.10.402)
0810400 Z30	GEAR REVOLUTIONS Z=30 (08.10.403) IT: INGRANAGGIO GIRI Z=30 (08.10.403)
0810400 Z32	GEAR REVOLUTIONS Z=32 (08.10.404) IT: INGRANAGGIO GIRI Z=32 (08.10.404)
0810400 Z38	GEAR REVOLUTIONS Z=38 (08.10.405) IT: INGRANAGGIO GIRI Z=38 (08.10.405)
0810400 Z40	GEAR REVOLUTIONS Z=40 (08.10.601) IT: INGRANAGGIO GIRI Z=40 (08.10.601)
0810400 Z41	GEAR REVOLUTIONS Z=41 (08.10.406) IT: INGRANAGGIO GIRI Z=41 (08.10.406)
0810400 Z42	GEAR REVOLUTIONS Z=42 (08.10.602) IT: INGRANAGGIO GIRI Z=42 (08.10.602)
0810400 Z43	GEAR REVOLUTIONS Z=43 (08.10.407) IT: INGRANAGGIO GIRI Z=43 (08.10.407)
0810400 Z44	GEAR REVOLUTIONS Z=44 (08.10.603) IT: INGRANAGGIO GIRI Z=44 (08.10.603)
0810400 Z46	GEAR REVOLUTIONS Z=46 (08.10.604) IT: INGRANAGGIO GIRI Z=46 (08.10.604)
0810400 Z47	GEAR REVOLUTIONS Z=47 (08.10.408) IT: INGRANAGGIO GIRI Z=47 (08.10.408)
0810400 Z48	GEAR REVOLUTIONS Z=48 (08.10.605) IT: INGRANAGGIO GIRI Z=48 (08.10.605)
0810400 Z49	GEAR REVOLUTIONS Z=49 (08.10.409) IT: INGRANAGGIO GIRI Z=49 (08.10.409)
0810400 Z50	GEAR REVOLUTIONS Z=50 (08.10.606) IT: INGRANAGGIO GIRI Z=50 (08.10.606)
0810400 Z52	GEAR REVOLUTIONS Z=52 (08.10.410) IT: INGRANAGGIO GIRI Z=52 (08.10.410)
0810400 Z58	GEAR REVOLUTIONS Z=58 (08.10.411) IT: INGRANAGGIO GIRI Z=58 (08.10.411)
0810400 Z60	GEAR REVOLUTIONS Z=60 (08.10.412) IT: INGRANAGGIO GIRI Z=60 (08.10.412)
0810400 Z61	GEAR REVOLUTIONS Z=61 (08.10.413) IT: INGRANAGGIO GIRI Z=61 (08.10.413)
0810400 Z63	GEAR REVOLUTIONS Z=63 (08.10.414) IT: INGRANAGGIO GIRI Z=63 (08.10.414)
0801008	GEAR SATELLITE GEAR for GILD.AS/GS/GM20 IT: INGRANAGGIO SATELLITE x GILD.AS/GS/GM20
0810400 Z45	GEAR Z=45 (SPECIAL) IT: INGRANAGGIO Z=45 (SPECIALE)
0840201	HUB IT: MOZZO
1417107	HUB IT: MOZZO
1640651	HUB IT: MOZZO
2279108	HUB IT: MOZZO
0513017	HUB WITH WHEEL Z=29 IT: MOZZO CON RUOTA Z=29
1551454	HUB WORM SCREW GILD.AS16/20 IT: MOZZO COCLEA GILD.AS16/20

1420101	HUB cam carrier DOUBLE IT: MOZZO PORTACAMME DOPPIO
1406004	HUB cam carrier POS.5 IT: MOZZO PORTACAMMA POS.5
1406101	HUB cam carrier SINGLE IT: MOZZO PORTACAMME SINGOLO
3117115	KEY for CLUTCH IT: CHIAVETTA x FRIZIONE
0801009	KEY for GEAR SATELLITE GEAR GILD.AS/GS/GM20 IT: CHIAVETTA x INGRANAGGIO SATELLITE GILD.AS/GS/GM20
0127024	PIN FOR CAMS RADIAL POS.3-4-5-6 IT: PERNO PER CAMME RADIALI POS.3-4-5-6
0607010	PIN for CAMS FRONT (20004231) IT: PERNO x CAMME FRONTALI (20004231)
0509008	PIN for CAMS RADIAL POS.1-2 IT: PERNO x CAMME RADIALI POS.1-2
1406102	PIN for CLAMPING CAMS GILD.AS/GS/GM20 IT: SPINA x BLOCCAGGIO CAMME GILD.AS/GS/GM20
0505019	PIN for CLAMPING CAMS GILD.AS16 IT: SPINA x BLOCCAGGIO CAMME GILD.AS16
0509401	PIN for CONNECTING ROD IT: PERNO x BIELLA
1404001	PIN for SHAFT 31.04.114 IT: PERNO x ALBERO 31.04.114
1516204	PULLEY IT: PULEGGIA
4516107	PULLEY IT: PULEGGIA
4516113	PULLEY IT: PULEGGIA
1416201	PULLEY MOTOR (F=42) IT: PULEGGIA MOTORE (F=42)
1416201 M	PULLEY MOTOR SPECIAL (F=38) IT: PULEGGIA MOTORE SPECIALE (F=38)
0517004	RING SPLINED for SHAFT OVERLOAD IT: ANELLO SCANALATO x ALBERO SOVRACCARICO
0805102	RING TOOTHED for CAMS IT: ANELLO DENTATO x CAMME
0127025	ROLLER FOR CAMS RADIAL IT: RULLO PER CAMME RADIALI
0607009	ROLLER for CAMS FRONT/AXIAL GILD.AS/GS/GM20 (20004232) IT: RULLO x CAMME FRONTALI/ASSIALI GILD.AS/GS/GM20 (20004232)
0822003	SCREW M10 OF STOP for BOTTOM CAMS POS.1/2/4/5 IT: VITE M10 DI FERMO x FONDO CAMME POS.1/2/4/5
0508008	SCREW M10 OF STOP for BOTTOM CAMS POS.3/6 IT: VITE M10 DI FERMO x FONDO CAMME POS.3/6
0804101	SHAFT IT: ALBERO
0810012	SHAFT IT: ALBERO
0813002	SHAFT IT: ALBERO
1510004	SHAFT IT: ALBERO
3117136	SHAFT IT: ALBERO

3117140	SHAFT IT: ALBERO
0505012	SHAFT A CAMS IT: ALBERO A CAMME
0505016	SHAFT A CAMS IT: ALBERO A CAMME
1112103	SHAFT CENTRAL GILD.AS/GS/GM20 IT: ALBERO CENTRALE GILD.AS/GS/GM20
0801003	SHAFT CENTRAL for GILD.AS16 IT: ALBERO CENTRALE x GILD.AS16
1504105	SHAFT ECCENTRIC for TRANSLATION MOTION IT: ALBERO ECCENTRICO x TRASLAZIONE
0518039	SHAFT FOR PUMP A GEARS IMIS 16 IT: ALBERO PER POMPA A INGRANAGGI IMIS 16
0810009	SHAFT IDLE IT: ALBERO FOLLE
0810007	SHAFT IDLER TRANSMISSION II IT: ALBERO RINVIO II
0810006	SHAFT INTERMEDIATE IT: ALBERO INTERMEDIO
0810010	SHAFT INTERMEDIATE IT: ALBERO INTERMEDIO
0869108	SHAFT SPLINED IT: ALBERO SCANALATO
1419008	SHAFT STOP GILD.AS16 IT: ALBERO FERMO GILD.AS16
3104114	SHAFT TRANSLATION MOTION IT: ALBERO TRASLAZIONE
1406001	SHAFT TRANSMISSION IT: ALBERO TRASMISSIONE
1417001	SHAFT for CLUTCHES IT: ALBERO x FRIZIONI
1417005	SHAFT for CLUTCHES IT: ALBERO x FRIZIONI
3117118	SHAFT for CLUTCHES IT: ALBERO x FRIZIONI
1517015	SHAFT for PULLEY AS16/20 (05.18.034) IT: ALBERO x PULEGGIA AS16/20 (05.18.034)
3117108	SHAFT for PULLEY GS/GM20 IT: ALBERO x PULEGGIA GS/GM20
1515201	SHAFT for PUMP A GEARS GILD. AS16-AS/GS/GM20 IT: ALBERO x POMPA A INGRANAGGI GILD. AS16-AS/GS/GM20
0517009	SPRING for OVERLOAD R.H. (CLUTCHES) IT: MOLLA x SOVRACCARICO DX (FRIZIONI)
3158103	STUB SHAFT CARRIER BEARINGS for ACCUMULATOR PICK-UP PNEUMATIC GILD.GS/GM20 IT: ALBERINO PORTA CUSCINETTI x POLMONE PICK-UP PNEUMATICO GILD.GS/GM20
4558273	STUB SHAFT CARRIER BEARINGS for ACCUMULATOR PICK-UP PNEUMATIC GILD.GS/GM20 IT: ALBERINO PORTA CUSCINETTI x POLMONE PICK-UP PNEUMATICO GILD.GS/GM20
0847018	STUB SHAFT for ACCUMULATOR IT: ALBERINO x POLMONE
3123103	STUB SHAFT for WORM SCREW IT: ALBERINO x COCLEA
3123103/1	STUB SHAFT for WORM SCREW WITH OVERLOAD IT: ALBERINO x COCLEA CON SOVRACCARICO
0810008	WASHER for CLAMPING GEARS PRODUCTION Øe29 IT: RONDELLA x BLOCCAGGIO INGRANAGGI PRODUZIONE Øe29

0810002	WASHER for CLAMPING GEARS REVOLUTIONS GILD.20 Øe49 / CONTROL FEEDS GILD.GM35 IT: RONDELLA x BLOCCAGGIO INGRANAGGI GIRI GILD.20 Øe49 / COMANDO AVANZAMENTI GILD.GM35
1417013	WEDGE for CLUTCH FEED IT: CUNEO x FRIZIONE AVANZAMENTO
1417201	WEDGE for CLUTCH THREADING IT: CUNEO x FRIZIONE FILETTATURA
0810015	WHEEL IT: RUOTA
0817007	WHEEL IT: RUOTA
1418002	WHEEL IT: RUOTA
1506003	WHEEL IT: RUOTA
0810016	WHEEL DOUBLE for TRANSLATION MOTION 0.7" IT: RUOTA DOPPIA x TRASLAZIONE 0.7"
0505001	WHEEL HELICAL IN BRONZE IT: RUOTA ELICOIDALE IN BRONZO
1406003	WHEEL HELICAL IN BRONZE IT: RUOTA ELICOIDALE IN BRONZO
0513012	WHEEL IDLER TRANSMISSION IT: RUOTA RINVIO
0513006	WHEEL IDLER TRANSMISSION Z=24 IT: RUOTA RINVIO Z=24
1417106S	WHEEL SHAFT CRANK GILD. GS20 (SPECIAL) IT: RUOTA ALBERO MANOVELLA GILD. GS20 (SPECIALE)
1517018/36	WHEEL SPECIAL Z=36 IT: RUOTA SPECIALE Z=36
1517019/55	WHEEL SPECIAL Z=55 IT: RUOTA SPECIALE Z=55
1504003	WHEEL TAPERED IT: RUOTA CONICA
1506004	WHEEL TAPERED IT: RUOTA CONICA
1506005	WHEEL TAPERED IT: RUOTA CONICA
1506006	WHEEL TAPERED IT: RUOTA CONICA
1506007	WHEEL TAPERED IT: RUOTA CONICA
1506004 R	WHEEL TAPERED (YES COUPLES WITH ART. 08 17 007 P) IT: RUOTA CONICA (SI ACCOPPIA CON ART. 08 17 007 P)
0506001	WHEEL TOOTHED IT: RUOTA DENTATA
0810018	WHEEL TOOTHED IT: RUOTA DENTATA
1504103	WHEEL TOOTHED IT: RUOTA DENTATA
1504104	WHEEL TOOTHED IT: RUOTA DENTATA
1506002	WHEEL TOOTHED IT: RUOTA DENTATA
1517019	WHEEL TOOTHED (08.10.001) IT: RUOTA DENTATA (08.10.001)
1517018	WHEEL TOOTHED (08.10.020) IT: RUOTA DENTATA (08.10.020)

1517101	WHEEL X CONTROL MANUAL IT: RUOTA X COMANDO MANUALE
0810017	WHEEL Z=27 IT: RUOTA Z=27
1417011	WHEEL Z=33 (Engagement Direct) IT: RUOTA Z=33 (Innesto Diretto)
4560127	WHEEL Z=35 IT: RUOTA Z=35
3117137	WHEEL Z=40 IT: RUOTA Z=40
4517106	WHEEL Z=40 IT: RUOTA Z=40
3117125	WHEEL Z=42 IT: RUOTA Z=42
3160194	WHEEL Z=43 for N.2 POSITIONING A 180° IT: RUOTA Z=43 x N.2 POSIZIONAMENTI A 180°
3160191	WHEEL Z=43 for N.2 POSITIONING A 90° IT: RUOTA Z=43 x N.2 POSIZIONAMENTI A 90°
3160198	WHEEL Z=43 for N.3 POSITIONING A 120° IT: RUOTA Z=43 x N.3 POSIZIONAMENTI A 120°
4560143	WHEEL Z=43 for N.4 POSITIONING A 90° IT: RUOTA Z=43 x N.4 POSIZIONAMENTI A 90°
3117138	WHEEL Z=45 IT: RUOTA Z=45
0840202	WHEEL Z=48 IT: RUOTA Z=48
3117126	WHEEL Z=48 IT: RUOTA Z=48
0810019	WHEEL Z=53 for TRANSLATION MOTION 0.7" IT: RUOTA Z=53 x TRASLAZIONE 0.7"
0814002	WHEEL for COUNTER-ROTATING GILD.AS/GS/GM20 IT: RUOTA x CONTROROTANTE GILD.AS/GS/GM20
3111185	WHEEL for HATCH IT: RUOTA x PORTELLONE
3111185S	WHEEL for HATCH IT: RUOTA x PORTELLONE
0814003	WHEEL for SYNCHRONOUS GILD.AS/GS/GM20 IT: RUOTA x SINCRONO GILD.AS/GS/GM20
0814004	WHEEL for THREADING GILD.AS/GS/GM20 IT: RUOTA x FILETTATURA GILD.AS/GS/GM20
1506001	cam carrier shaft for CARRIAGES RADIAL GILD.AS/GS/GM20 IT: ALBERO PORTA CAMME x CARRELLI RADIALI GILD.AS/GS/GM20

Feed, Control & Slides		92
3122128 M	BUSHING IN BRONZE for LEVER THRUST AXIAL IT: BOCCOLA IN BRONZO x LEVA SPINTA ASSIALE	
4521001	CONTROL AXIAL for GILD.GM20 POS.1 IT: COMANDO ASSIALE x GILD.GM20 POS.1	
4521002	CONTROL AXIAL for GILD.GM20 POS.2 IT: COMANDO ASSIALE x GILD.GM20 POS.2	
4521003	CONTROL AXIAL for GILD.GM20 POS.4 IT: COMANDO ASSIALE x GILD.GM20 POS.4	
4521004	CONTROL AXIAL for GILD.GM20 POS.5 IT: COMANDO ASSIALE x GILD.GM20 POS.5	

3127001	CONTROL SUPPORT CENTRAL GILD.AS/GS/GM20 IT: COMANDO SUPPORTO CENTRALE GILD.AS/GS/GM20
1511013	COVER SLIDE POS.1 IT: COPERCHIO SLITTA POS.1
0512020	COVER SLIDE POS.2 IT: COPERCHIO SLITTA POS.2
0820008	COVER SLIDE POS.3 IT: COPERCHIO SLITTA POS.3
1411014	COVER SLIDE POS.4/5 IT: COPERCHIO SLITTA POS.4/5
4524001	FEELER for REVERSAL THREADING LL=140,5 IT: TASTATORE x INVERSIONE FILETTATURA LL=140,5
0509103	GIB for SLIDE AXIAL POS.1-4 IT: LARDONE x SLITTA ASSIALE POS.1-4
0509303	GIB for SLIDE AXIAL POS.2-5 IT: LARDONE x SLITTA ASSIALE POS.2-5
3109108	GUARD for SLIDE RADIAL GILD.AS/GS/GM20 POS.1-2 IT: PROTEZIONE x SLITTA RADIALE GILD.AS/GS/GM20 POS.1-2
3107126	GUARD for SLIDE RADIAL GILD.AS/GS/GM20 POS.3 (SC4552337) IT: PROTEZIONE x SLITTA RADIALE GILD.AS/GS/GM20 POS.3 (SC4552337)
3107131	GUARD for SLIDE RADIAL GILD.AS/GS/GM20 POS.6 IT: PROTEZIONE x SLITTA RADIALE GILD.AS/GS/GM20 POS.6
1407101	INSERT SLIDE GILD.20 POS.3/6 IT: TASSELLO SLITTA GILD.20 POS.3/6
1527005	INSERT for LEVER CONTROL SUPPORT CENTRAL IT: TASSELLO x LEVA COMANDO SUPPORTO CENTRALE
1527006	INSERT for LEVER CONTROL SUPPORT CENTRAL IT: TASSELLO x LEVA COMANDO SUPPORTO CENTRALE
1527001	LEVER CONTROL SUPPORT CENTRAL IT: LEVA COMANDO SUPPORTO CENTRALE
3122114 F	LEVER POS.4 FRONT ART. 08 07 003 F (CASTING) IT: LEVA POS.4 FRONTALE ART. 08 07 003 F (FUSIONE)
3122115 F	LEVER POS.5 FRONT ART. 08 07 001 F (CASTING - TYPE CAST IRON GS500) IT: LEVA POS.5 FRONTALE ART. 08 07 001 F (FUSIONE - TIPO GHISA GS500)
0509009	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.1 IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.1
0509205	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.2 IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.2
0820003	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.3/6 IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.3/6
0510002	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.4 IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.4
0861101	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.4 for ROLLING IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.4 x RULLATURA
0510201	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.5 IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.5
0861201	LEVER SLIDE RADIAL GILD.AS16/20 GS/GM20 POS.5 for ROLLING IT: LEVA SLITTA RADIALE GILD.AS16/20 GS/GM20 POS.5 x RULLATURA
3158304	LEVER SPECIAL for PICK-UP GILD.GM20 POS.3 (F.24) IT: LEVA SPECIALE x PICK-UP GILD.GM20 POS.3 (F.24)
3158303	LEVER SPECIAL for PICK-UP GILD.GM20 POS.6 F.24 (30230101) IT: LEVA SPECIALE x PICK-UP GILD.GM20 POS.6 F.24 (30230101)
3121105	LEVER for THRUST AXIAL GILD.GS/GM20 (F.24) POS.1/5 (15.21.101) IT: LEVA x SPINTA ASSIALE GILD.GS/GM20 (F.24) POS.1/5 (15.21.101)
3121106	LEVER for THRUST AXIAL GILD.GS/GM20 (F.24) POS.2/4 (15.21.201) IT: LEVA x SPINTA ASSIALE GILD.GS/GM20 (F.24) POS.2/4 (15.21.201)

4524001/1	NUT FEELER for REVERSAL THREADING (08.09.306) IT: DADO TASTATORE x INVERSIONE FILETTATURA (08.09.306)
0111026	PIN LEVERS FRONT (20004204) IT: PERNO LEVE FRONTALI (20004204)
0508026	PIN X REG. RATIOS SLIDES RADIAL POS.3-6 (05.07.003) IT: PERNO X REG. RAPPORTI SLITTE RADIALI POS.3-6 (05.07.003)
0820106	PIN for CARRIAGE POS.3 IT: PERNO x CARRO POS.3
1527002	PIN for LEVER CONTROL SUPPORT CENTRAL IT: PERNO x LEVA COMANDO SUPPORTO CENTRALE
0509001	PIN for LEVER RADIAL POS.1/2 IT: PERNO x LEVA RADIALE POS.1/2
0508014	PIN for LEVER RADIAL POS.3/6 IT: PERNO x LEVA RADIALE POS.3/6
0510001	PIN for LEVER RADIAL POS.4/5 IT: PERNO x LEVA RADIALE POS.4/5
1046103	PIN for LEVER ROLLING POS.4/5 IT: PERNO x LEVA RULLATURA POS.4/5
0509012	PIN for REG. RATIOS SLIDES RADIAL POS.1-2-4-5 IT: PERNO x REG. RAPPORTI SLITTE RADIALI POS.1-2-4-5
0509012S	PIN for REG. RATIOS SLIDES RADIAL POS.1-2-4-5 SPECIAL A DRAWING Ø7.95h8 IT: PERNO x REG. RAPPORTI SLITTE RADIALI POS.1-2-4-5 SPECIALE A DISEGNO Ø7.95h8
0101405	PIN for SLEEVE CARRIER SMALL LEVERS GILD.GM16-AS/GS/GM20-GM35/42 IT: SPINA x MANICOTTO PORTA LEVETTE GILD.GM16-AS/GS/GM20-GM35/42
0502003	PIN for SLIDE SHOE IT: PERNO x PATTINO
0820006	PIN for SLIDES RADIAL IT: PERNO x SLITTE RADIALI
0820105	PIN for SLIDES RADIAL IT: PERNO x SLITTE RADIALI
3107119	PLATE CARRIAGE GM20 POS.3 IT: PIASTRA CARRO GM20 POS.3
3109106	PLATE CARRIAGE POS.1 GILD.20 IT: PIASTRA CARRO POS.1 GILD.20
0509104	PLATE for SLIDE POS.1 IT: PIASTRA x SLITTA POS.1
0509304	PLATE for SLIDE POS.2-5 IT: PIASTRA x SLITTA POS.2-5
0510302	PLATE for SLIDE POS.4 IT: PIASTRA x SLITTA POS.4
3101107	RING for SLEEVE lever holder GILD. GS/GM20 IT: ANELLO x MANICOTTO PORTALEVETTE GILD. GS/GM20
0801302	RING for SLEEVE lever holder GILD.AS16/20 IT: ANELLO x MANICOTTO PORTALEVETTE GILD.AS16/20
0508018	ROD IT: ASTA
0510004	ROD IT: ASTA
0847015	ROD IT: ASTA
1517104	ROD IT: ASTA
1522013	ROD IT: ASTA
3158264	ROD OF GUIDE Ø14 IT: ASTA DI GUIDA Ø14

0129006	ROD SPRING GUIDE IT: ASTA GUIDAMOLLA
0509003	ROD STOP POSITIVE IT: ASTA FERMO POSITIVO
1521301	ROD for THRUST AXIAL IT: ASTA x SPINTA ASSIALE
1521102	ROD for THRUST AXIAL GILD.AS/GS/GM20 POS.4/5 IT: ASTA x SPINTA ASSIALE GILD.AS/GS/GM20 POS.4/5
1504106	ROLLER for TRANSLATION MOTION IT: RULLO x TRASLAZIONE
4524001/2	SCREW FEELER for REVERSAL THREADING (08.09.307) IT: VITE TASTATORE x INVERSIONE FILETTATURA (08.09.307)
0127306	SCREW for ADJUSTMENT GIB CARRIAGE AXIAL IT: VITE x REGOLAZIONE LARDONE CARRO ASSIALE
0509011	SCREW for ADJUSTMENT POSITION SLIDE RADIAL GILD.AS16 AS/GS/GM20 POS.1/2/4/5 IT: VITE x REGOLAZIONE POSIZIONE SLITTA RADIALE GILD.AS16 AS/GS/GM20 POS.1/2/4/5
1521108	SCREW for LEVER THRUST AXIAL GILD.AS/GS/GM20 IT: VITE x LEVA SPINTA ASSIALE GILD.AS/GS/GM20
1521304	SCREW for ROD THRUST AXIAL GILD.AS/GS/GM20 IT: VITE x ASTA SPINTA ASSIALE GILD.AS/GS/GM20
0801301	SLEEVE CARRIER SMALL LEVERS for GILD.AS16/20 IT: MANICOTTO PORTA LEVETTE x GILD.AS16/20
3160202	SLEEVE CARRIER SMALL LEVERS for GILD.GS/GM20 (31.01.106) IT: MANICOTTO PORTA LEVETTE x GILD.GS/GM20 (31.01.106)
0509102S	SLIDE AXIAL GILD.20 POS.1/4 (Special) IT: SLITTA ASSIALE GILD.20 POS.1/4 (Speciale)
0509302S	SLIDE AXIAL GILD.20 POS.2/5 (Special) IT: SLITTA ASSIALE GILD.20 POS.2/5 (Speciale)
0802003	SLIDE SHOE IT: PATTINO
1509103	SLIDE SHOE IT: PATTINO
0802003 3M	SLIDE SHOE ECCENTRIC 1mm (31.02.102) IT: PATTINO ECCENTRICO 1mm (31.02.102)
0802003 4M	SLIDE SHOE ECCENTRIC 2mm (31.02.103) IT: PATTINO ECCENTRICO 2mm (31.02.103)
1517402	SLIDE SHOE ENGAGEMENT IT: PATTINO INNESTO
0525655	SMALL LEVER IT: LEVETTA
1405006	SMALL LEVER IT: LEVETTA
084230	SMALL LEVERS GILDEMEISTER AS16-20 IT: LEVETTE GILDEMEISTER AS16-20
1408201	SMALL PLATE SLIDE POS.1/4 IT: PIASTRINA SLITTA POS.1/4
1408103	SMALL PLATE SLIDE POS.2/5 IT: PIASTRINA SLITTA POS.2/5
1411047	SMALL PLATE for GUARD SLIDE IT: PIASTRINA x PROTEZIONE SLITTA
1527003	SPACER for LEVER CONTROL SUPPORT CENTRAL IT: DISTANZIALE x LEVA COMANDO SUPPORTO CENTRALE
1558115	SPRING for CONTROL M.D.R. HYDRAULIC GM20 (20004223) IT: MOLLA x COMANDO M.D.R. IDRAULICO GM20 (20004223)
0509013	SPRING for PIN ADJUSTMENT RATIOS SLIDES RADIAL IT: MOLLA x PERNO REGISTRAZIONE RAPPORTI SLITTE RADIALI

0133553	SPRING for SLEEVE CARRIER SMALL LEVERS GILD.GM16-AS/GS/GM20-GM35/42 IT: MOLLA x MANICOTTO PORTA LEVETTE GILD.GM16-AS/GS/GM20-GM35/42
1407102	VERNIER for CARRIAGE GILD.AS/GS20 IT: NONIO x CARRO GILD.AS/GS20
3107118	VERNIER for CARRIAGE GILD.GM20 IT: NONIO x CARRO GILD.GM20

Pneumatics & Hydraulics 8

3158255	CYLINDER POS.6 IT: CILINDRO POS.6
0847007	PISTON IT: PISTONE
0847011	PISTON IT: PISTONE
1558147	PISTON IT: PISTONE
1558148	PISTON IT: PISTONE
3158257	PISTON IT: PISTONE
3158258	PISTON IT: PISTONE
4558268	PISTON IT: PISTONE

Bearings, Rings & Rotating Components 67

20093606	BEARING for CLOSURE REINFORCED GILD.AS16/20 IT: CUSCINETTO x CHIUSURA RINFORZATA GILD.AS16/20
0509451	BLOCK for THRUST AXIAL IT: BLOCCHETTO x SPINTA ASSIALE
1521111	BLOCK for THRUST AXIAL IT: BLOCCHETTO x SPINTA ASSIALE
1417004	BRONZE BUSHING IT: BRONZINA
1504114	BRONZE BUSHING IT: BRONZINA
3158137/6	BRONZE BUSHING Ø 6 IT: BRONZINA Ø 6
4558238	BRONZE BUSHING Ø 8 (31.58.137/8) IT: BRONZINA Ø 8 (31.58.137/8)
1518201	BUSHING IT: BOCCOLA
1519007	BUSHING IT: BOCCOLA
1519008	BUSHING IT: BOCCOLA
1521103	BUSHING IT: BOCCOLA
1521651	BUSHING IT: BOCCOLA
1521652	BUSHING IT: BOCCOLA
1551256	BUSHING IT: BOCCOLA

1551304	BUSHING IT: BOCCOLA
1623103	BUSHING IT: BOCCOLA
3001110	BUSHING IT: BOCCOLA
3122128	BUSHING IT: BOCCOLA
0818005	BUSHING --> TO USE 08.18.005 M IT: BOCCOLA --> UTILIZZARE 08.18.005 M
0847001/6	BUSHING IN BRONZE Ø6 IT: BOCCOLA IN BRONZO Ø6
0847153	BUSHING IN BRONZE Ø6 IT: BOCCOLA IN BRONZO Ø6
0847001	BUSHING IN BRONZE Ø8 IT: BOCCOLA IN BRONZO Ø8
0818005 M	BUSHING SEMI-FINISHED Ø8 IT: BOCCOLA SEMILAVORATA Ø8
0804302	BUSHING SPLINED IT: BOCCOLA SCANALATA
1510003	BUSHING SPLINED IT: BOCCOLA SCANALATA
20096304	BUSHING for REST SMALL HAMMER CLOSURE REINF.. GILD.AS16/20-GS20 IT: BOCCOLA x APPOGGIO MARTELLETTO CHIUSURA RINF. GILD.AS16/20-GS20
0801018	BUSHING for REST SMALL HAMMER GILD. AS16/20 IT: BOCCOLA x APPOGGIO MARTELLETTO GILD. AS16/20
3101110	BUSHING for REST SMALL HAMMER GILD. GS/GM20 IT: BOCCOLA x APPOGGIO MARTELLETTO GILD. GS/GM20
2801108	BUSHING for REST SMALL HAMMER GILD. GS/GM20 FAST IT: BOCCOLA x APPOGGIO MARTELLETTO GILD. GS/GM20 VELOCE
1512151 B	BUSHING for TUBE BUNDLE IT: BOCCOLA x TUBO FASCIO
1512151 BM	BUSHING for TUBE BUNDLE - MODIFIED IT: BOCCOLA x TUBO FASCIO - MODIFICATA
4558235	BUSHING Ø8 (31.58.136) IT: BOCCOLA Ø8 (31.58.136)
4501113	DISC stop holder for DRUM GM20 IT: DISCO PORTAFERMI x TAMBURRO GM20
1504116	DRUM IT: TAMBURRO
0801452	DRUM for STOP "C" IT: TAMBURRO x FERMO "C"
3101158 L10	FELT for DRUM GILD.AS16/AS20 (3for10for1000mm 70.42.43) IT: FELTRO x TAMBURRO GILD.AS16/AS20 (3x10x1000mm 70.42.43)
3101158 L8	FELT for DRUM GILD.GS/GM20 (3for8for1000mm) IT: FELTRO x TAMBURRO GILD.GS/GM20 (3x8x1000mm)
0806008	KEY POS.4/5 AXIAL IT: CHIAVETTA POS.4/5 ASSIALE
0509452	KEY for BLOCK THRUST AXIAL IT: CHIAVETTA x BLOCCHETTO SPINTA ASSIALE
0101016	NUT for STOP POSITIVE DRUM IT: DADO x FERMO POSITIVO TAMBURRO
1521107	PIN for THRUST AXIAL IT: PERNO x SPINTA ASSIALE
4511122	PLUG IN ALUMINUM for UPRIGHT THRUST AXIAL POS.1/2 - ARM OSCILLATING IT: TAPPO IN ALLUMINIO x MONTANTE SPINTA ASSIALE POS.1/2 - BRACCIO OSCILLANTE

4804205	PLUG IN ALUMINUM for UPRIGHT THRUST AXIAL POS.4/5 IT: TAPPO IN ALLUMINIO x MONTANTE SPINTA ASSIALE POS.4/5
0514009	RING IT: ANELLO
0525658	RING IT: ANELLO
0847024	RING IT: ANELLO
0847031	RING IT: ANELLO
1417109	RING IT: ANELLO
1558143	RING IT: ANELLO
2279101	RING IT: ANELLO
2802206	RING IT: ANELLO
1413252	RING CONTROL THREADING GILD.20 IT: ANELLO CONTROLLO FILETTATURA GILD.20
0525259	RING for SMALL ARM OSCILLATING IT: ANELLO x BRACCINO OSCILLANTE
0106615	ROLLER IT: RULLO
0124186	ROLLER IT: RULLO
0207012	ROLLER IT: RULLO
1522009	ROLLER IT: RULLO
0507006	ROLLER for LATCH IT: RULLO x CHIAVISTELLO
0822005	SCREW M10X1 STOP POSITIVE RADIAL IT: VITE M10X1 FERMO POSITIVO RADIALE
0509006	SCREW for ADJUSTMENT GIB RADIAL GILD.AS/GS/GM20 POS.1/2/4/5 IT: VITE x REGOLAZIONE LARDONE RADIALE GILD.AS/GS/GM20 POS.1/2/4/5
0508004	SCREW for ADJUSTMENT GIB RADIAL GILD.AS/GS/GM20 POS.3/6 IT: VITE x REGOLAZIONE LARDONE RADIALE GILD.AS/GS/GM20 POS.3/6
0101026	SCREW for STOP POSITIVE DRUM IT: VITE x FERMO POSITIVO TAMBURIO
3101138	SECTOR for DRUM GM20 IT: SETTORE x TAMBURIO GM20
1501004	SPACER for BEARING REAR DRUM IT: DISTANZIALE x CUSCINETTO POSTERIORE TAMBURIO
1501905	SPACER for DRUM IT: DISTANZIALE x TAMBURIO
32111505	SPRING REINFORCED for CARRIAGES RADIAL GILD.AS/GS/GM20 (08.63.013) IT: MOLLA RINFORZATA x CARRI RADIALI GILD.AS/GS/GM20 (08.63.013)
0129033	SPRING for CARRIAGES RADIAL GILD.AS/GS/GM20 IT: MOLLA x CARRI RADIALI GILD.AS/GS/GM20

Springs & Elastic Components		19
0517002	SPRING IT: MOLLA	

0525662	SPRING IT: MOLLA
0803004	SPRING IT: MOLLA
0847025	SPRING IT: MOLLA
0853306	SPRING IT: MOLLA
1401004	SPRING IT: MOLLA
1501007	SPRING IT: MOLLA
1519028	SPRING IT: MOLLA
1521110	SPRING IT: MOLLA
1527016	SPRING IT: MOLLA
0514008D	SPRING A CUP IT: MOLLA A TAZZA
1501003	SPRING A CUP Øe70 Øi41.9 SP.4 for GILD.AS/GS/GM20 IT: MOLLA A TAZZA Øe70 Øi41.9 SP.4 x GILD.AS/GS/GM20
0127314	SPRING GUIDE IT: GUIDAMOLLA
1519030	SPRING GUIDE IT: GUIDAMOLLA
117530	SPRING LATCH (05.07.008) IT: MOLLA CHIAVISTELLO (05.07.008)
4542101	SPRING WITH EYELETS for ARM OSCILLATING IT: MOLLA CON OCCHIELLI x BRACCIO OSCILLANTE
0525257	SPRING for ARM FOR PICK-UP GIL.AS/GS/GM20 IT: MOLLA x BRACCIO DA RIPRESA GIL.AS/GS/GM20
1640210	SPRING for ARM OSCILLATING IT: MOLLA x BRACCIO OSCILLANTE
0134907	SPRING for CARRIAGES AXIAL GILD.AS/GS/GM20 IT: MOLLA x CARRI ASSIALI GILD.AS/GS/GM20

Fasteners & Small Parts	89
-------------------------	----

1030555	GIB IT: LARDONE
3107109	GIB IT: LARDONE
2276064	GRUB SCREW IT: GRANO
0804010	INSERT IT: TASSELLO
4566104	INSERT IT: TASSELLO
0111025	INSERT (20004221) IT: TASSELLO (20004221)
0808009	INSERT for CASING GILD.GM16/20/35 IT: TASSELLO x CARTER GILD.GM16/20/35
0808009-S	INSERT for CASING LEFT IT: TASSELLO x CARTER SINISTRO

0808009-D	INSERT for CASING RIGHT <i>IT: TASSELLO x CARTER DESTRO</i>
0110043	KEY <i>IT: CHIAVETTA</i>
0840203	KEY <i>IT: CHIAVETTA</i>
1047411	KEY <i>IT: CHIAVETTA</i>
1501606	KEY <i>IT: CHIAVETTA</i>
2801258	KEY <i>IT: CHIAVETTA</i>
3117116	KEY <i>IT: CHIAVETTA</i>
3119106	KEY <i>IT: CHIAVETTA</i>
3119126	KEY <i>IT: CHIAVETTA</i>
3160134	KEY <i>IT: CHIAVETTA</i>
0801009S	KEY SPECIAL <i>IT: CHIAVETTA SPECIALE</i>
0127310	NUT <i>IT: DADO</i>
0520302	NUT <i>IT: DADO</i>
1522008	NUT <i>IT: DADO</i>
1527012	NUT <i>IT: DADO</i>
1558118	NUT <i>IT: DADO</i>
1558123	NUT <i>IT: DADO</i>
0514008C	NUT CH24 M15for1 <i>IT: DADO CH24 M15x1</i>
3160154	NUT M12for1 <i>IT: DADO M12x1</i>
0106608	PIN <i>IT: PERNO</i>
0501007	PIN <i>IT: PERNO</i>
0502007	PIN <i>IT: PERNO</i>
0503021	PIN <i>IT: PERNO</i>
0507009	PIN <i>IT: SPINA</i>
0541114	PIN <i>IT: PERNO</i>
0541121	PIN <i>IT: PERNO</i>
0802005	PIN <i>IT: SPINA</i>
0820007	PIN <i>IT: PERNO</i>

0820104	PIN IT: PERNO
0826101B	PIN IT: SPINA
0835262	PIN IT: PERNO
0853202	PIN IT: PERNO
0853305	PIN IT: PERNO
0858356	PIN IT: PERNO
1405005	PIN IT: PERNO
1513603	PIN IT: PERNO
1521105	PIN IT: PERNO
1640203	PIN IT: PERNO
3108104	PIN IT: SPINA
3158286	PIN IT: SPINA
3160125	PIN IT: PERNO
3160127	PIN IT: PERNO
3779123	PIN IT: SPINA
4560190	PIN IT: PERNO
0507002	PIN LATCH IT: PERNO CHIAVISTELLO
0807012	PIN VERNIER FRONT GILD.20 IT: PERNO NONI FRONTALI GILD.20
0114756	PIN for CROSS MALTA IT: PERNO x CROCE MALTA
1405003	PIN for LATCH IT: PERNO x CHIAVISTELLO
0819011	PIN for SMALL PULLEY IT: PERNO x CARRUCOLA
0509109	SCREW IT: VITE
0519002	SCREW IT: VITE
0520301	SCREW IT: VITE
0813004	SCREW IT: VITE
0822004	SCREW IT: VITE
0834056	SCREW IT: VITE
0834358	SCREW IT: VITE

1301068	SCREW IT: VITE
1408102	SCREW IT: VITE
1522007	SCREW IT: VITE
1525018	SCREW IT: VITE
1558135	SCREW IT: VITE
3107116	SCREW IT: VITE
3779124	SCREW IT: VITE
4566105	SCREW IT: VITE
4566106	SCREW IT: VITE
1511025	SCREW M6 TURNED for PANELS GIL.GM16/20/35 IT: VITE M6 TORNITA x SPORTELLI GIL.GM16/20/35
0806308	SCREW OF ADJUSTMENT IT: VITE DI REGOLAZIONE
0844101	SCREW OF ADJUSTMENT IT: VITE DI REGOLAZIONE
0517013	SCREW WITHOUT END GILD.AS/GS/GM20 IT: VITE SENZA FINE GILD.AS/GS/GM20
1501611	SCREW for KEY IT: VITE x CHIAVETTA
1525013	SCREW for SMALL SUPPORT IT: VITE x SUPPORTINO
0901450	SCREW for STOP C (09.01.451+09.01.452) IT: VITE x FERMO C (09.01.451+09.01.452)
1423008	SCREW for WORM SCREW IT: VITE x COCLEA
0106611	WASHER IT: RONDELLA
0517016	WASHER IT: RONDELLA
1402002	WASHER IT: RONDELLA
1503002	WASHER IT: RONDELLA
1519020	WASHER IT: RONDELLA
1519800	WASHER IT: RONDELLA
1522010	WASHER IT: RONDELLA
3117141	WASHER IT: RONDELLA
Supports, Plates & Structural Components	
1513604	ANGLE BRACKET IT: SQUADRA

4566102	ANGLE BRACKET IT: SQUADRA
3113240	ANGLE BRACKET micrometer holder L.H. IT: SQUADRA PORTAMICRO SX
0858360	ARM IT: BRACCIO
0509002	BLOCK IT: BLOCCETTO
0521007	BLOCK IT: BLOCCETTO
0524202	BLOCK IT: BLOCCETTO
1109101	BLOCK IT: BLOCCETTO
1511016	BLOCK IT: BLOCCETTO
1513302	BLOCK IT: BLOCCETTO
1513601	BLOCK IT: BLOCCETTO
1513602	BLOCK IT: BLOCCETTO
1521305	BLOCK IT: BLOCCETTO
3114158	BLOCK IT: BLOCCETTO
3119123	BLOCK IT: BLOCCETTO
0112002 A35	BLOCK A=35 Ø14 IT: BLOCCETTO A=35 Ø14
0112002 A55	BLOCK A=55 Ø14 IT: BLOCCETTO A=55 Ø14
0112002 A70	BLOCK A=70 Ø14 IT: BLOCCETTO A=70 Ø14
4514102	BLOCK HIGH PRESSURE GM20 IT: BLOCCETTO ALTA PRESSIONE GM20
4514104	BLOCK HIGH PRESSURE GM20 IT: BLOCCETTO ALTA PRESSIONE GM20
4514238	BLOCK HIGH PRESSURE GM20 IT: BLOCCETTO ALTA PRESSIONE GM20
0858355	BLOCK center holder Ø 10 IT: BLOCCETTO PORTAPUNTA Ø 10
3158208	BLOCK center holder Ø10 for ARM FOR PICK-UP GILD.GM20 IT: BLOCCETTO PORTAPUNTA Ø10 x BRACCIO DA RIPRESA GILD.GM20
0834357	BRACKET IT: STAFFA
0834505	BRACKET IT: STAFFA
1504101	CROSS OF MALTA IT: CROCE DI MALTA
0505011	FLANGE IT: FLANGIA
0519010	FLANGE IT: FLANGIA
0804008	FLANGE IT: FLANGIA

0809305	FLANGE IT: FLANGIA
0814010	FLANGE IT: FLANGIA
0814018	FLANGE IT: FLANGIA
0847014	FLANGE IT: FLANGIA
1103003	FLANGE IT: FLANGIA
1103005	FLANGE IT: FLANGIA
1510001	FLANGE IT: FLANGIA
1517004	FLANGE IT: FLANGIA
1518002	FLANGE IT: FLANGIA
1551306	FLANGE IT: FLANGIA
1558149	FLANGE IT: FLANGIA
3158259	FLANGE IT: FLANGIA
4558269	FLANGE IT: FLANGIA
1417015	FLANGE (14.17.002) IT: FLANGIA (14.17.002)
1415104	FLANGE PUMP GILD. AS20 IT: FLANGIA POMPA GILD. AS20
1412001	FLANGE for BUNDLE TUBES GILD.AS/GS/GM20 IT: FLANGIA x FASCIO TUBI GILD.AS/GS/GM20
1412001 F	FLANGE for BUNDLE TUBES GILD.AS/GS/GM20 (CASTING) IT: FLANGIA x FASCIO TUBI GILD.AS/GS/GM20 (FUSIONE)
0847004	FORK IT: FORCELLA
3158284	FORK IT: FORCELLA
1504102	FORK for CROSS OF MALTA IT: FORCELLA x CROCE DI MALTA
1551301	PLATE IT: PIASTRA
3113237	PLATE IT: PIASTRA
3119112	PLATE IT: PIASTRA
3158287	PLATE IT: PIASTRA
1513505	PLATE CARRIER MICRO for cross-shaped bracket IT: PIASTRA PORTA MICRO x SVASTICA
3113242	PLATE CARRIER MICRO for cross-shaped bracket IT: PIASTRA PORTA MICRO x SVASTICA
4524386	PLATE WITH CECCATURA X STAND AS/GS/GM20-GM32/35/42 IT: PIASTRA CON CECCATURA X PIANTANA AS/GS/GM20-GM32/35/42
1514102 16	PLATE X AS16 IT: PIASTRA X AS16

1511009	PLATE ZONE VALVES GILD. AS20 IT: PIASTRA ZONA RUBINETTI GILD. AS20
0834550	PLATE for GM20 POS.3 IT: PIASTRA x GM20 POS.3
0834551	PLATE for GM20 POS.3 IT: PIASTRA x GM20 POS.3
1504117 M	PLATE for MODIFICATION CROSS OF MALTA SHIM 12mm IT: PIASTRA x MODIFICA CROCE DI MALTA SPESSORE 12mm
1504117	PLATE for MODIFICATION CROSS OF MALTA SHIM 15mm IT: PIASTRA x MODIFICA CROCE DI MALTA SPESSORE 15mm
4804204	PLUG IN ALUMINUM for UPRIGHT ARM OSCILLATING IT: TAPPO IN ALLUMINIO x MONTANTE BRACCIO OSCILLANTE
0802007	SECTOR IT: SETTORE
0803013	SECTOR IT: SETTORE
3112102	SECTOR IN BAKELITE STAND GILD.AS/GS/GM20 IT: SETTORE IN BACHELITE PIANTANA GILD.AS/GS/GM20
3155105	SLEEVE IT: MANICOTTO
2801601	SLEEVE CARRIER LUGS IT: MANICOTTO PORTA NASELLI
20096305	SLEEVE for CLOSURE REINFORCED GILD.AS16/20-GS20 (20096302+20096303) IT: MANICOTTO x CHIUSURA RINFORZATA GILD.AS16/20-GS20 (20096302+20096303)
0525652	SMALL PLATE IT: PIASTRINA
0834852	SMALL PLATE IT: PIASTRINA
0858357	SMALL PLATE IT: PIASTRINA
1513401	SMALL PLATE IT: PIASTRINA
1519003	SMALL PLATE IT: PIASTRINA
1527013	SMALL PLATE IT: PIASTRINA
3108105	SMALL PLATE IT: PIASTRINA
3113238	SMALL PLATE micrometer holder IT: PIASTRINA PORTAMICRO
0504011	SPACER IT: DISTANZIALE
0504017	SPACER IT: DISTANZIALE
0513037	SPACER IT: DISTANZIALE
0518005	SPACER IT: DISTANZIALE
0518012	SPACER IT: DISTANZIALE
0518016	SPACER IT: DISTANZIALE
0518036	SPACER IT: DISTANZIALE
0801103	SPACER IT: DISTANZIALE

0801151	SPACER IT: DISTANZIALE
0801152	SPACER IT: DISTANZIALE
0804005	SPACER IT: DISTANZIALE
0804007	SPACER IT: DISTANZIALE
0805003	SPACER IT: DISTANZIALE
0810004	SPACER IT: DISTANZIALE
0810034	SPACER IT: DISTANZIALE
0810042	SPACER IT: DISTANZIALE
0812052	SPACER IT: DISTANZIALE
0814014	SPACER IT: DISTANZIALE
0814016	SPACER IT: DISTANZIALE
0814017	SPACER IT: DISTANZIALE
0853012	SPACER IT: DISTANZIALE
0853016	SPACER IT: DISTANZIALE
0853112	SPACER IT: DISTANZIALE
0869104	SPACER IT: DISTANZIALE
0869106	SPACER IT: DISTANZIALE
1405004	SPACER IT: DISTANZIALE
1417003	SPACER IT: DISTANZIALE
1421403	SPACER IT: DISTANZIALE
1501903	SPACER IT: DISTANZIALE
1504107	SPACER IT: DISTANZIALE
1504108	SPACER IT: DISTANZIALE
1504109	SPACER IT: DISTANZIALE
1504115	SPACER IT: DISTANZIALE
1510005	SPACER IT: DISTANZIALE
1518003	SPACER IT: DISTANZIALE
1519015	SPACER IT: DISTANZIALE

1523107	SPACER IT: DISTANZIALE
1551455	SPACER IT: DISTANZIALE
1558108	SPACER IT: DISTANZIALE
1558158	SPACER IT: DISTANZIALE
1558159	SPACER IT: DISTANZIALE
2279102	SPACER IT: DISTANZIALE
3101141	SPACER IT: DISTANZIALE
3101142	SPACER IT: DISTANZIALE
3117139	SPACER IT: DISTANZIALE
3122117	SPACER IT: DISTANZIALE
3126144	SPACER IT: DISTANZIALE
3158261	SPACER IT: DISTANZIALE
3158262	SPACER IT: DISTANZIALE
3158298	SPACER IT: DISTANZIALE
4558274	SPACER IT: DISTANZIALE
3117109	SPACER (08.10.036) IT: DISTANZIALE (08.10.036)
3117110	SPACER (08.10.043) IT: DISTANZIALE (08.10.043)
0810043	SPACER (31.17.110) IT: DISTANZIALE (31.17.110)
0804104 MP	SPACER MODIFIED IT: DISTANZIALE MODIFICATO
3101144	SPACER SEMI-FINISHED IT: DISTANZIALE SEMILAVORATO
0804002H1000	SPACER SP.10,00 (0804002) IT: DISTANZIALE SP.10,00 (0804002)
0804002H1010	SPACER SP.10,10 IT: DISTANZIALE SP.10,10
0804002H1020	SPACER SP.10,20 IT: DISTANZIALE SP.10,20
0804002H1030	SPACER SP.10,30 IT: DISTANZIALE SP.10,30
0804002H1040	SPACER SP.10,40 IT: DISTANZIALE SP.10,40
0804002H1050	SPACER SP.10,50 IT: DISTANZIALE SP.10,50
0804002H1060	SPACER SP.10,60 IT: DISTANZIALE SP.10,60
0804002H1070	SPACER SP.10,70 IT: DISTANZIALE SP.10,70

0804002H1080	SPACER SP.10,80 <i>IT: DISTANZIALE SP.10,80</i>
0804002H1090	SPACER SP.10,90 <i>IT: DISTANZIALE SP.10,90</i>
0505013	SPACER SP.11 mm <i>IT: DISTANZIALE SP.11 mm</i>
0804002H1100	SPACER SP.11,00 <i>IT: DISTANZIALE SP.11,00</i>
0504013	SPACER SP.3 (05.05.013) <i>IT: DISTANZIALE SP.3 (05.05.013)</i>
0804002H900	SPACER SP.9,00 <i>IT: DISTANZIALE SP.9,00</i>
0804002H910	SPACER SP.9,10 <i>IT: DISTANZIALE SP.9,10</i>
0804002H920	SPACER SP.9,20 <i>IT: DISTANZIALE SP.9,20</i>
0804002H930	SPACER SP.9,30 <i>IT: DISTANZIALE SP.9,30</i>
0804002H940	SPACER SP.9,40 <i>IT: DISTANZIALE SP.9,40</i>
0804002H950	SPACER SP.9,50 <i>IT: DISTANZIALE SP.9,50</i>
0804002H960	SPACER SP.9,60 <i>IT: DISTANZIALE SP.9,60</i>
0804002H970	SPACER SP.9,70 <i>IT: DISTANZIALE SP.9,70</i>
0804002H980	SPACER SP.9,80 <i>IT: DISTANZIALE SP.9,80</i>
0804002H990	SPACER SP.9,90 <i>IT: DISTANZIALE SP.9,90</i>
0810202/D	SPACER SPECIAL <i>IT: DISTANZIALE SPECIALE</i>
1417003H300	SPACER SPECIAL H=3,00 mm (05.18.012) <i>IT: DISTANZIALE SPECIALE H=3,00 mm (05.18.012)</i>
1417003H500	SPACER SPECIAL H=5,00 mm (05.18.012) <i>IT: DISTANZIALE SPECIALE H=5,00 mm (05.18.012)</i>
1417003H700	SPACER SPECIAL H=7,00 mm (05.18.012) <i>IT: DISTANZIALE SPECIALE H=7,00 mm (05.18.012)</i>
1504109/2	SPACER SPECIAL SP=2mm <i>IT: DISTANZIALE SPECIALE SP=2mm</i>
0801103S	SPACER SPECIAL for MODIFICATION V-RING <i>IT: DISTANZIALE SPECIALE x MODIFICA V-RING</i>
0847009	SPACER for ACCUMULATOR PICK-UP <i>IT: DISTANZIALE x POLMONE PICK-UP</i>
1514402	SPACER for PUMP MACHINE BED <i>IT: DISTANZIALE x POMPA BANCALE</i>
0847012	SUPPORT <i>IT: SUPPORTO</i>
1551302	SUPPORT <i>IT: SUPPORTO</i>
3112132	SUPPORT <i>IT: SUPPORTO</i>
1558154	SUPPORT PICK-UP <i>IT: SUPPORTO PICK-UP</i>
0818003	SUPPORT for BUNDLE TUBES <i>IT: SUPPORTO x FASCIO TUBI</i>

Miscellaneous / Special Components		101
2489F010	ADHESIVE "AS20 GILDEMEISTER" COLOR WHITE 48for14 IT: ADESIVO "AS20 GILDEMEISTER" COLORE BIANCO 48x14	
2489F032	ADHESIVE "DEMA GMD 620 AS" COLOR WHITE 48for17 IT: ADESIVO "DEMA GMD 620 AS" COLORE BIANCO 48x17	
2489F057	ADHESIVE "DEMA GMD 620 GS" COLOR WHITE 48for17 IT: ADESIVO "DEMA GMD 620 GS" COLORE BIANCO 48x17	
2489F030	ADHESIVE "DEMA GRD 616 AS" COLOR BLACK 40for14 IT: ADESIVO "DEMA GRD 616 AS" COLORE NERO 40x14	
2489F028	ADHESIVE "DEMA GRD 616 AS" COLOR BLACK 48for17 IT: ADESIVO "DEMA GRD 616 AS" COLORE NERO 48x17	
2489F029	ADHESIVE "DEMA GRD 616 AS" COLOR WHITE 40for14 IT: ADESIVO "DEMA GRD 616 AS" COLORE BIANCO 40x14	
2489F027	ADHESIVE "DEMA GRD 616 AS" COLOR WHITE 48for17 IT: ADESIVO "DEMA GRD 616 AS" COLORE BIANCO 48x17	
2489F031	ADHESIVE "DEMA GRD 620 AS" COLOR BLACK 48for17 IT: ADESIVO "DEMA GRD 620 AS" COLORE NERO 48x17	
2489F056	ADHESIVE "DEMA GRD 620 GS" COLOR BLACK 48for17 IT: ADESIVO "DEMA GRD 620 GS" COLORE NERO 48x17	
2489F015	ADHESIVE "GD20-AC" COLOR GREY 44,5for7,5 IT: ADESIVO "GD20-AC" COLORE GRIGIO 44,5x7,5	
2489F014	ADHESIVE "GM20 AC GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GM20 AC GILDEMEISTER" COLORE NERO 48x17	
2489F013	ADHESIVE "GM20 GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GM20 GILDEMEISTER" COLORE NERO 48x17	
2489F016	ADHESIVE "GM20-6 GILDEMEISTER" COLOR BLACK 63for8,5 IT: ADESIVO "GM20-6 GILDEMEISTER" COLORE NERO 63x8,5	
2489F011	ADHESIVE "GS20 GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GS20 GILDEMEISTER" COLORE NERO 48x17	
2489F012	ADHESIVE "GS20 GILDEMEISTER" COLOR WHITE 48for17 IT: ADESIVO "GS20 GILDEMEISTER" COLORE BIANCO 48x17	
4511048	ASSEMBLY HANDLE COVERS GILD.GM20 IT: GRUPPO MANIGLIA CAPOTTE GILD.GM20	
3160139	BODY (Complete of bushings) IT: CORPO (Completo di bussole)	
3123121	BOTTOM WORM SCREW GILD.GS/GM20 IT: FONDO COCLEA GILD.GS/GM20	
0847023	BUSHING IT: BUSSOLA	
1519016	BUSHING IT: BUSSOLA	
2287103	BUSHING IT: BUSSOLA	
3160138	BUSHING IT: BUSSOLA	
1502051 F	CASTING IT: FUSIONE	
3158266	CLAMP IT: MORSETTO	
4558104	CLAMP IT: MORSETTO	
3112131	COLUMN IT: COLONNA	

0802002	COLUMN for GILD.AS/GS/GM20 IT: COLONNA x GILD.AS/GS/GM20
0512031	COVER IT: COPERCHIO
0801502	DISC OF SUPPORT STANDARD IT: DISCO DI SOSTEGNO STANDARD
4526281	DISTRIBUTOR VALVE IT: DISTRIBUTORE
4566103	DRAWING FOR DRILLING ADDITIONAL IT: DISEGNO PER FORATURA AGGIUNTIVA
1560302	EXTENSION IT: PROLUNGA
1417016	FITTING IT: RACCORDO
1411017	FLAT IT: PIATTO
3111183	GASKET 600for500for21.4mm FOR GLASS CARRIER STANDARD GILD.GM20-GM32/35/42 IT: GUARNIZIONE 600x500x21.4mm PER VETRO PORTA STANDARD GILD.GM20-GM32/35/42
0525654	HOOK IT: GANCIO
0840012	HOOK IT: GANCIO
1701513	HOOK IT: GANCIO
1758070	HOOK IT: GANCIO
3119115	HOOK IT: GANCIO
1514101	HOUSING VALVES GILD. AS20 IT: SCATOLA RUBINETTI GILD. AS20
1521109	INDEX IT: INDICE
0525129	JOINT IT: SNODO
1558141	JOINT IT: SNODO
4517115	KEY 12for8for40 IT: LINGUETTA 12x8x40
0521005	KNOB IT: MANOPOLA
1558107	LINER IT: CAMICIA
3101143	PAIR SPACERS (3101144+3101145) IT: COPPIA DISTANZIALI (3101144+3101145)
3723169	PAWL IT: NOTTOLINO
3719120	PAWL Ø20 mm IT: NOTTOLINO Ø20 mm
3719120/25	PAWL Ø25 mm IT: NOTTOLINO Ø25 mm
0517003	PEG IT: PIOLO
0525657	PEG IT: PIOLO
1519027	PEG IT: PIOLO

0852004	PINION TAPERED IT: PIGNONE CONICO
0810041	PLUG IT: TAPPO
1401101	PLUG IT: TAPPO
1507102	PLUG IT: TAPPO
4526114	PLUG IT: TAPPO
4526132	PLUG IT: TAPPO
3104101	PLUGS ALUMINUM GS IT: TAPPI ALLUMINIO GS
3158277	QUILL PICK-UP LL=194 A=156 (31.58.072) IT: CANOTTO PICK-UP LL=194 A=156 (31.58.072)
3158278	QUILL PICK-UP LL=214 A=176 (31.58.073) IT: CANOTTO PICK-UP LL=214 A=176 (31.58.073)
3158279	QUILL PICK-UP LL=234 A=196 (31.58.074). IT: CANOTTO PICK-UP LL=234 A=196 (31.58.074).
3158280	QUILL PICK-UP LL=254 A=216 (31.58.075) IT: CANOTTO PICK-UP LL=254 A=216 (31.58.075)
3158281	QUILL PICK-UP LL=274 A=236 (31.58.076) IT: CANOTTO PICK-UP LL=274 A=236 (31.58.076)
3158282	QUILL PICK-UP LL=294 A=256 (31.58.077) IT: CANOTTO PICK-UP LL=294 A=256 (31.58.077)
2240H083	REDUCTION CYLINDRICAL 3/8-3/8 for VALVE AS/GS/GM20 IT: RIDUZIONE CILINDRICA 3/8-3/8 x RUBINETTO AS/GS/GM20
0847030	SHIM IT: SPESSORE
0847000P	SMALL ACCUMULATOR for AS16 IT: POLMONCINO x AS16
0801012	SMALL COLUMN IT: COLONNINA
3160113	SMALL COLUMN IT: COLONNINA
1551456	SMALL DISC IT: DISCHETTO
0507004	SMALL ROLLER LATCH IT: RULLINO CHIAVISTELLO
0503014	SMALL WASHER IT: ROSETTA
0801021	SMALL WASHER OF SAFETY IT: ROSETTA DI SICUREZZA
0819012	SMALL WHEEL IT: ROTELLA
2279107	SOLID BLOCK IT: MASSELLO
0814008	SPINDLE STUB IT: FUSO
3126143	SPINDLE STUB IT: FUSO
0847157	STOP IT: FERMO
1519023	STOP IT: FERMO

1527014	STOP IT: FERMO
3119129	STOP IT: FERMO
3158265	STOP IT: FERMO
4526282	STOP IT: FERMO
3160132	STOP POSITIONER IT: FERMO POSIZIONATORE
0514008	STRIP IT: REGOLO
0525651	STRIP IT: REGOLO
1558142	STRIP IT: REGOLO
0514008B	STRIP SPECIAL IT: REGOLO SPECIALE
0858359	STUD IT: PRIGIONIERO
0106616	THRUST RING IT: RALLA
0804003	TUBE (INCLUDED OF 08.04.005) IT: TUBO (INCLUSO DI 08.04.005)
1510002	TUBE OF GUARD IT: TUBO DI PROTEZIONE
2240H082	VALVE AIGNEP 3/8" M/F IT: RUBINETTO AIGNEP 3/8" M/F
3779125	VERNIER IT: NONIO
1418003	WEDGE IT: CUNEO
0834651S	boring bar holder SPECIAL Ø16 IT: PORTABARENO SPECIALE Ø16
0834651	boring bar holder Ø10 IT: PORTABARENO Ø10
1513504	cross-shaped bracket IT: SVASTICA

Gildemeister GM32 / GM35 / GM42 Spare Parts

565 part numbers · price on request

Chucks, Collets & Bar Clamping		100
4001111	BEARING for BELL HOUSING GILD.GM42 IT: CUSCINETTO x CAMPANA GILD.GM42	
3501134	BEARING for BELL HOUSING open/close COLLET GILD.GM32/35 IT: CUSCINETTO x CAMPANA A/C PINZA GILD.GM32/35	
4201196	BEARING for BELL HOUSING open/close COLLET GILD.GM35/8 IT: CUSCINETTO x CAMPANA A/C PINZA GILD.GM35/8	
3523114	BELL HOUSING IT: CAMPANA	
3501132	BELL HOUSING open/close COLLET GILD. GM32/35-6 IT: CAMPANA A/C PINZA GILD. GM32/35-6	
4201292	BELL HOUSING open/close COLLET GILD. GM35/8 IT: CAMPANA A/C PINZA GILD. GM35/8	
4001109	BELL HOUSING open/close COLLET GILD.GM42 IT: CAMPANA A/C PINZA GILD.GM42	
3722107	BUSHING SPLINED for front spindle GM32/35 IT: BUSSOLA SCANALATA x MANDRINO FRONTALE GM32/35	
4922103	BUSHING for CLAMPING front spindles GILD.GM32/35/42 IT: BUSSOLA x BLOCCAGGIO MANDRINI FRONTALI GILD.GM32/35/42	
3523134	CLAMP for front spindle IT: MORSETTO x MANDRINO FRONTALE	
2245H401	CLUTCH MECHANICAL DOUBLE for GILD.GM35 STOP SPINDLE (07.23.61) IT: FRIZIONE MECCANICA DOPPIA x GILD.GM35 STOP MANDRINO (07.23.61)	
3501118	COLLAR NUT IT: GHIERA	
3501135	COLLAR NUT IT: GHIERA	
3510139	COLLAR NUT IT: GHIERA	
3522129	COLLAR NUT IT: GHIERA	
3723114	COLLAR NUT IT: GHIERA	
3725115	COLLAR NUT IT: GHIERA	
3758197	COLLAR NUT IT: GHIERA	
3758220	COLLAR NUT IT: GHIERA	
4958105	COLLAR NUT IT: GHIERA	
4923148	COLLAR NUT (SC5254122) IT: GHIERA (SC5254122)	
3501146	COLLAR NUT CARRIER BUSHING BAR GUIDE for DRAW ROD GILD.GM35 IT: GHIERA PORTA BUSSOLA GUIDABARRA x TIRANTE GILD.GM35	
3501133	COLLAR NUT for BELL HOUSING GILD.GM32/35 IT: GHIERA x CAMPANA GILD.GM32/35	
4922105	COLLAR NUT for COUPLING front spindles GILD.GM32/35/42 IT: GHIERA x GIUNTO MANDRINI FRONTALI GILD.GM32/35/42	

3501145	COLLAR NUT for DRAW ROD FEED BAR GILD.GM35/42 IT: GHIERA x TIRANTE AVANZAMENTO BARRA GILD.GM35/42
3522110	COLLAR NUT for FORK for GILD.GM32/35 IT: GHIERA x FORCELLA x GILD.GM32/35
3701232	COLLAR NUT for GILD.GM32/35 IT: GHIERA x GILD.GM32/35
4951191	COLLAR NUT for SPINDLE IT: GHIERA x MANDRINO
3701108	COLLAR NUT for SPINDLE GILD.GM32/35 IT: GHIERA x MANDRINO GILD.GM32/35
4001128	COLLAR NUT for SPINDLE GILD.GM42 IT: GHIERA x MANDRINO GILD.GM42
4001142	COLLAR NUT for SPINDLE GILD.GM42 IT: GHIERA x MANDRINO GILD.GM42
4001164	COLLAR NUT for SPINDLE GILD.GM42 IT: GHIERA x MANDRINO GILD.GM42
3701230	COMPENSATOR for DRAW ROD collet holder GILD.GM32/35 IT: COMPENSATORE x TIRANTE PORTAPINZA GILD.GM32/35
3722114	CONNECTING ROD for front spindle GILD.GM32/35 IT: BIELLA x MANDRINO FRONTALE GILD.GM32/35
4925128	DRAW ROD IT: TIRANTE
4901111	DRAW ROD BAR CLAMP GILD.GM42 IT: TIRANTE STRINGIBARRA GILD.GM42
3501148	DRAW ROD BAR CLAMP for GM32/35 (37.01.009) IT: TIRANTE STRINGIBARRA x GM32/35 (37.01.009)
3501148M	DRAW ROD BAR CLAMP for GM32/35 SPECIAL IT: TIRANTE STRINGIBARRA x GM32/35 SPECIALE
3760114	DRAW ROD BAR CLAMP for GM32/35 STOP SPINDLE (37.01.054) IT: TIRANTE STRINGIBARRA x GM32/35 STOP MANDRINO (37.01.054)
3707106	DRAW ROD COMPLETE OF JOINTS (see 4907210) IT: TIRANTE COMPLETO DI SNODI (vedi 4907210)
4958107	DRAW ROD CONNECTION BAYONET IT: TIRANTE ATTACCO BAIONETTA
3501149	DRAW ROD COUNTER-COLLET (THREAD.L.H.) FOR GILD.GM32 (37.01.012) IT: TIRANTE CONTROPINZA (FIL.SX) PER GILD.GM32 (37.01.012)
3701147	DRAW ROD COUNTER-COLLET (THREAD.L.H.) FOR GILD.GM35 (37.01.033) IT: TIRANTE CONTROPINZA (FIL.SX) PER GILD.GM35 (37.01.033)
3701102	DRAW ROD COUNTER-COLLET (THREAD.R.H.) FOR GILD.GM32 (37.01.011) IT: TIRANTE CONTROPINZA (FIL.DX) PER GILD.GM32 (37.01.011)
3701146	DRAW ROD COUNTER-COLLET (THREAD.R.H.) for GILD.GM35 (37.01.032) IT: TIRANTE CONTROPINZA (FIL.DX) x GILD.GM35 (37.01.032)
4901110	DRAW ROD FEED BAR (THREAD.R.H.) FOR GM42 (49.01.156) IT: TIRANTE AVANZAMENTO BARRA (FIL.DX) PER GM42 (49.01.156)
3707123	DRAW ROD SLIDE RADIAL GILD.GM35 POS.4-5 IT: TIRANTE SLITTA RADIALE GILD.GM35 POS.4-5
4301161	DRAW ROD collet holder GIL.GM26 IT: TIRANTE PORTA PINZA GIL.GM26
3712128	DRAW ROD for STOP BAR GILD.GM35 IT: TIRANTE x FERMO BARRA GILD.GM35
4223006V1	ELEMENTS for front spindle IT: ELEMENTI x MANDRINO FRONTALE
4923025V1	ELEMENTS for front spindle (With lubrication) IT: ELEMENTI x MANDRINO FRONTALE (Con lubrificazione)
4923023V1	ELEMENTS for front spindle (Without lubrication) IT: ELEMENTI x MANDRINO FRONTALE (Senza lubrificazione)

4910161	FLANGE for CONTROL ROTATION front spindle GM35/42 IT: FLANGIA x COMANDO ROTAZIONE MANDRINO FRONTALE GM35/42
3502105	FORK for OPENING/CLOSURE COLLET GILD. GM32/35 IT: FORCELLA x APERTURA/CHIUSURA PINZA GILD. GM32/35
4002101	FORK for OPENING/CLOSURE COLLET GILD. GM42 IT: FORCELLA x APERTURA/CHIUSURA PINZA GILD. GM42
4922108	FORK for front spindle GILD.GM32/35 IT: FORCELLA x MANDRINO FRONTALE GILD.GM32/35
3760241	GEAR Z22 for POSITIONING SPINDLE GM32/35 IT: INGRANAGGIO Z22 x POSIZIONAMENTO MANDRINO GM32/35
3523131	GIB SPINDLE ROTATING GILD. GM32-35-42 IT: LARDONE MANDRINO ROTANTE GILD. GM32-35-42
4923347	GIB for front spindle GILD.GM32/35/42 (SEMI-FINISHED) IT: LARDONE x MANDRINO FRONTALE GILD.GM32/35/42 (SEMILAVORATO)
4923349	GUIDE LL=340 for front spindle GILD.GM32/35/42 IT: GUIDA LL=340 x MANDRINO FRONTALE GILD.GM32/35/42
3701109B	HUB WHEEL TOOTHED FOR MODIFICATION GILD. GM32 STOP SPINDLE IT: MOZZO RUOTA DENTATA PER MODIFICA GILD. GM32 STOP MANDRINO
3501109	KEY COLLET for GILD. GM32/35 IT: CHIAVETTA PINZA x GILD. GM32/35
4001130	KEY COLLET for GILD. GM42 IT: CHIAVETTA PINZA x GILD. GM42
3758204	KEY for COLLET pick-up spindle GILD.GM32/35 (Q39) IT: CHIAVETTA x PINZA MANDRINO DA RIPRESA GILD.GM32/35 (Q39)
3502109	LEVER open/close COLLET GILD.GM32/35 IT: LEVA A/C PINZA GILD.GM32/35
3702111	PIN SUPPORT open/close COLLET GILDEMEISTER GM35 IT: SPINA SUPPORTO A/C PINZA GILDEMEISTER GM35
3760161	PIN for DRUM STOP SPINDLES GILD.GM35 IT: PERNO x TAMBURLO ARRESTO MANDRINI GILD.GM35
3502104	PIN for OPENING/CLOSURE COLLET GILD.GM32/35 IT: PERNO x APERTURA/CHIUSURA PINZA GILD.GM32/35
4922104	RING A CROSS for COUPLING front spindle GM32/35 IT: ANELLO A CROCE x GIUNTO MANDRINO FRONTALE GM32/35
3502103	ROLLER for OPENING/CLOSURE COLLET GILD.GM32/35 IT: RULLO x APERTURA/CHIUSURA PINZA GILD.GM32/35
4923346	SCREW for ADJUSTMENT GIB front spindle GILD.GM32/35 (49.23.111) IT: VITE x REGISTRO LARDONE MANDRINO FRONTALE GILD.GM32/35 (49.23.111)
3723258	SCREW for CLAMPING front spindle GM32/35 IT: VITE x BLOCCAGGIO MANDRINO FRONTALE GM32/35
3701233	SCREW for COMPENSATOR ADJUSTMENT COLLET GILD.GM32/35/42 (L=16mm) IT: VITE x COMPENSATORE REGISTRAZIONE PINZA GILD.GM32/35/42 (L=16mm)
3501108	SLEEVE collet holder for GILD. GM32/35 IT: BICCHIERE PORTA PINZA x GILD. GM32/35
4001129	SLEEVE collet holder for GILD. GM42 IT: BICCHIERE PORTA PINZA x GILD. GM42
3723101	SLIDE SPINDLE ROTATING GILD. GM32-35-42 IT: COULISSE MANDRINO ROTANTE GILD. GM32-35-42
3760162	SMALL COLUMN GILD.GM35 STOP SPINDLE IT: COLONNINA GILD.GM35 STOP MANDRINO
3501130	SMALL LEVER FOR open/close COLLET GILD. GM32/GM35-6 (10.0631) IT: LEVETTA PER A/C PINZA GILD. GM32/GM35-6 (10.0631)
4001113	SMALL LEVER FOR open/close COLLET GILD. GM42 (10.0642) IT: LEVETTA PER A/C PINZA GILD. GM42 (10.0642)
5701299	SMALL LEVER FOR open/close COLLET GILD. GMC42 (10.0654) IT: LEVETTA PER A/C PINZA GILD. GMC42 (10.0654)

3501107	SPACER for SPINDLE GILD. GM32/35 IT: DISTANZIALE x MANDRINO GILD. GM32/35
4001103	SPACER for SPINDLE GILD. GM42 IT: DISTANZIALE x MANDRINO GILD. GM42
4923151	SPINDLE IT: MANDRINO
4923143	SPINDLE (IN ALTERNATIVE TO USE 49.23.151) IT: MANDRINO (IN ALTERNATIVA USARE 49.23.151)
3701101	SPINDLE PORTAB.NORM IT: MANDRINO PORTAB.NORM
3760151	SPINDLE STUB for DRUM STOP SPINDLES GILD.GM35 IT: FUSO x TAMBURRO ARRESTO MANDRINI GILD.GM35
3722106	SPINDLE STUB for front spindle GILD.GM32/35 IT: FUSO x MANDRINO FRONTALE GILD.GM32/35
4922106	SPRING A CUP for COUPLING front spindles GILD.GM32/35/42 IT: MOLLA A TAZZA x GIUNTO MANDRINI FRONTALI GILD.GM32/35/42
3722149	SPRING for LEVERS front spindles GILD.GM32/35/42 IT: MOLLA x LEVE MANDRINI FRONTALI GILD.GM32/35/42
4923144 B	STOP for front spindle GILD.GM32/35/42 (H=12mm) IT: FERMO x MANDRINO FRONTALE GILD.GM32/35/42 (H=12mm)
4923144	STOP for front spindle GILD.GM32/35/42 (H=17mm) IT: FERMO x MANDRINO FRONTALE GILD.GM32/35/42 (H=17mm)
3723158	STOP for front spindle GM32-35-42 TYPE OLD IT: FERMO x MANDRINO FRONTALE GM32-35-42 TIPO VECCHIO
4223006V2	SUPPORT for front spindle IT: SUPPORTO x MANDRINO FRONTALE
4923025V2	SUPPORT for front spindle IT: SUPPORTO x MANDRINO FRONTALE
4923140	SUPPORT for front spindle GILD.GM32/35/42 IT: SUPPORTO x MANDRINO FRONTALE GILD.GM32/35/42
4920103	WRENCH OF EXTRACTION for front spindle GILD.GM32/35/42 IT: CHIAVE DI ESTRAZIONE x MANDRINO FRONTALE GILD.GM32/35/42
4923026	front spindle FIXED for GILD. GM32/35/42 (With Lubrication) IT: MANDRINO FRONTALE FISSO x GILD. GM32/35/42 (Con Lubrificazione)
4923025	front spindle ROTATING for GILD. GM32/35/42 (With Lubrication) IT: MANDRINO FRONTALE ROTANTE x GILD. GM32/35/42 (Con Lubrificazione)
4923023	front spindle ROTATING for GILD. GM32/35/42 (Without Lubrication) IT: MANDRINO FRONTALE ROTANTE x GILD. GM32/35/42 (Senza Lubrificazione)
4223006	front spindle ROTATING for GILD. GM35/8 (With Lubrication) IT: MANDRINO FRONTALE ROTANTE x GILD. GM35/8 (Con Lubrificazione)

Bar Feed & Guide		62
4212138	BAR STOP IN WIDIA for GILD.GM35/8 <i>IT: FERMOBARRA IN WIDIA x GILD.GM35/8</i>	
3781125	BRACKET FOR SMALL LEVER END BAR POS.1 <i>IT: STAFFA PER LEVETTA FINE BARRA POS.1</i>	
4930104	CAM STOP BAR for LOADER PIETRO CUCCHI for GILD.GM32/35/42 <i>IT: CAMMA FERMO BARRA x CARICATORE PIETRO CUCCHI x GILD.GM32/35/42</i>	
3712117	CLAMP BAND for STOP BAR GILD.GM35 <i>IT: FASCETTA x FERMO BARRA GILD.GM35</i>	
3712122	CLAMP BAND for STOP BAR GILD.GM35 <i>IT: FASCETTA x FERMO BARRA GILD.GM35</i>	
3712132	CLAMP for STOP BAR GILD.GM35 <i>IT: MORSETTO x FERMO BARRA GILD.GM35</i>	

3712127	DISC TERMINAL for STOP BAR GILD.GM35 IT: DISCO TERMINALE x FERMO BARRA GILD.GM35
3712114	DISC for STOP BAR IT: DISCO x FERMO BARRA
4951146	EYEBOLT FOR SUPPORT ENGAGEMENT bar guides GILD.GM35/42 IT: GOLFARE PER SUPPORTO INNESTO PORTABARRE GILD.GM35/42
3714101GM32 CM	FLANGE for TUBE bar guide GM32 IT: FLANGIA x TUBO PORTABARRA GM32
3714101GM358 CM	FLANGE for TUBE bar guide GM35/8 IT: FLANGIA x TUBO PORTABARRA GM35/8
3714101GM42 CM	FLANGE for TUBE bar guide GM42 IT: FLANGIA x TUBO PORTABARRA GM42
3712121	FORK FOR STOP BAR GILD.GM35 IT: FORCELLA PER FERMO BARRA GILD.GM35
3512114	KEY FOR STOP BAR GILD.GM35 IT: LINGUETTA PER FERMO BARRA GILD.GM35
3703107M	LEVER for APPLICATION EXCLUSION FEED BAR GILD.GM32/35/42 IT: LEVA x APPLICAZIONE ESCLUSIONE AVANZAMENTO BARRA GILD.GM32/35/42
3703109	PAD FEED BAR GILD.GM35 IT: PASTICCA AVANZAMENTO BARRA GILD.GM35
3101102	PAD FOR bar guides GILD.GM32/35/42 IT: PASTICCA PER PORTABARRE GILD.GM32/35/42
3512116	PAD IN WIDIA for BAR STOP GILD.GM32/35/42 IT: PASTICCA IN WIDIA x FERMOBARRA GILD.GM32/35/42
4912101	PAD IN WIDIA for BAR STOP GILD.GM32/35/42 OVERSIZED IT: PASTICCA IN WIDIA x FERMOBARRA GILD.GM32/35/42 MAGGIORATA
2279105	PIN CONVEYOR GILDEMEISTER GM32 IT: PERNO CONVOGLIATORE GILDEMEISTER GM32
3503104	PIN FEED BAR GILD.GM35 IT: PERNO AVANZAMENTO BARRA GILD.GM35
3503107	PIN FEED BAR GILD.GM35 IT: PERNO AVANZAMENTO BARRA GILD.GM35
3701135	PIN FOR SUPPORT ENGAGEMENT bar guides GILD.GM32/35/42 IT: PERNO PER SUPPORTO INNESTO PORTABARRE GILD.GM32/35/42
3701110	PIN FOR SUPPORT bar guides GILD.GM32/35/42 (49.51.151) IT: PERNO PER SUPPORTO PORTABARRE GILD.GM32/35/42 (49.51.151)
2279105M10	PIN M10 CONVEYOR GILDEMEISTER GM32 IT: PERNO M10 CONVOGLIATORE GILDEMEISTER GM32
3503107M	PIN for APPLICATION EXCLUSION FEED BAR GILD. GM32-35-42 GM32-35-42 IT: PERNO x APPLICAZIONE ESCLUSIONE AVANZAMENTO BARRA GILD. GM32-35-42 GM32-35-42
3712111	PIN for STOP BAR IT: PERNO x FERMO BARRA
3712115	PIN for STOP BAR GILD.GM35 IT: PERNO x FERMO BARRA GILD.GM35
3712120	PIN for STOP BAR GILD.GM35 IT: PERNO x FERMO BARRA GILD.GM35
3703105	PLATE FEED BAR GILD.GM32/35 IT: PIASTRA AVANZAMENTO BARRA GILD.GM32/35
3503112	RING FEED BAR GILD.GM32/35/42 IT: ANELLO AVANZAMENTO BARRA GILD.GM32/35/42
3703128	ROLLER for FEED BAR GM32/35 IT: RULLO x AVANZAMENTO BARRA GM32/35
3712110	ROLLER for STOP BAR IT: RULLO x FERMO BARRA
3712116	ROLLER for STOP BAR GILD.GM35 IT: RULLO x FERMO BARRA GILD.GM35

3712133	SCREW FOR STOP BAR GILD.GM35 IT: VITE PER FERMO BARRA GILD.GM35
3701134	SCREW SUPPORT ENGAGEMENT bar guides GILD.GM35/42 IT: VITE SUPPORTO INNESTO PORTABARRE GILD.GM35/42
3503114	SECTOR FEED BAR GILD.GM32/35 IT: SETTORE AVANZAMENTO BARRA GILD.GM32/35
3719113	SHAFT LONG FOR CONVEYOR GILD. GM32/35/42 IT: ALBERO LUNGO PER CONVOGLIATORE GILD. GM32/35/42
3719115	SHAFT SHORT FOR CONVEYOR GILD. GM32/35/42 IT: ALBERO CORTO PER CONVOGLIATORE GILD. GM32/35/42
3712106	SHAFT for STOP BAR IT: ALBERO x FERMO BARRA
3701127	SLIDE SHOE IN BRONZE for FEED BAR GILD.GM32/35 IT: PATTINO IN BRONZO x AVANZAMENTO BARRA GILD.GM32/35
4001125	SLIDE SHOE IN BRONZE for FEED BAR GILD.GM42 IT: PATTINO IN BRONZO x AVANZAMENTO BARRA GILD.GM42
3703106	SMALL PLATE FOR LEVER FEED BAR GILD.GM32/35/42 IT: PIASTRINA PER LEVA AVANZAMENTO BARRA GILD.GM32/35/42
3712162	SMALL PLATE for STOP BAR GILD.GM35 IT: PIASTRINA x FERMO BARRA GILD.GM35
3503106	SPACER FEED BAR GILD.GM35 IT: DISTANZIALE AVANZAMENTO BARRA GILD.GM35
3714161	SPACER bar guides GILD.GM35 IT: DISTANZIALE PORTABARRE GILD.GM35
3303116	SPRING FEED BAR GILD.GM35 IT: MOLLA AVANZAMENTO BARRA GILD.GM35
3712118	SPRING STOP BAR GILD.GM32/42/35 (With Exclusion) IT: MOLLA FERMO BARRA GILD.GM32/42/35 (Con Esclusione)
3712105	SPRING STOP BAR GILD.GM35 IT: MOLLA FERMO BARRA GILD.GM35
3712124	SPRING TENSIONER X BAR STOP GM35 LL=74mm IT: TENDIMOLLA X FERMOBARRA GM35 LL=74mm
3712123	SPRING TENSIONER for STOP BAR GILD.GM35 LL=45mm IT: TENDIMOLLA x FERMO BARRA GILD.GM35 LL=45mm
3714015	SPRING for BUNDLE TUBE GUIDE GM32/35 L=3000 (BAR D.0/8) IT: MOLLA x FASCIO TUBIERO GM32/35 L=3000 (BARRA D.0/8)
3714017	SPRING for BUNDLE TUBE GUIDE GM32/35 L=3000 (BAR D.14/21) IT: MOLLA x FASCIO TUBIERO GM32/35 L=3000 (BARRA D.14/21)
3714018	SPRING for BUNDLE TUBE GUIDE GM32/35 L=3000 (BAR D.21/32) IT: MOLLA x FASCIO TUBIERO GM32/35 L=3000 (BARRA D.21/32)
3714019	SPRING for BUNDLE TUBE GUIDE GM32/35 L=3000 (BAR D.32/35) IT: MOLLA x FASCIO TUBIERO GM32/35 L=3000 (BARRA D.32/35)
3714016	SPRING for BUNDLE TUBE GUIDE GM32/35 L=3000 (BAR D.8/14) IT: MOLLA x FASCIO TUBIERO GM32/35 L=3000 (BARRA D.8/14)
4912111	SPRING for STOP BAR (STANDARD) IT: MOLLA x FERMO BARRA (STANDARD)
3705117	SPRING for STOP BAR GILD.GM32/35 (Eyelets Swiveling) IT: MOLLA x FERMO BARRA GILD.GM32/35 (Occhielli Girevoli)
4912009	STOP BAR WITH EXCLUSION GILD.GM35 IT: FERMO BARRA CON ESCLUSIONE GILD.GM35
3714101B GM32	TUBE bar guide for BUNDLE TUBE GUIDE GILD.GM32 L=3000 IT: TUBO PORTABARRA x FASCIO TUBIERO GILD.GM32 L=3000
3714101B GM42	TUBE bar guide for BUNDLE TUBE GUIDE GILD.GM42 L=3000 IT: TUBO PORTABARRA x FASCIO TUBIERO GILD.GM42 L=3000
3719111	WHEEL CHAIN TENSIONER FOR CONVEYOR GILD. GM32/35/42 IT: RUOTA TENDICATENA PER CONVOGLIATORE GILD. GM32/35/42

Tool Heads & Tooling		9
3723004	THREADING HEAD (ASSEMBLY CLUTCHES + IDLER TRANSMISSION MOTION INTERNAL) GILD.GM32/35/42 IT: FILETTATORE (GRUPPO FRIZIONI + RINVIO MOTO INTERNO) GILD.GM32/35/42	
4035101	tool holder IT: PORTAUTENSILE	
4035108	tool holder IT: PORTAUTENSILE	
4035111	tool holder IT: PORTAUTENSILE	
4035113	tool holder IT: PORTAUTENSILE	
4035003	tool holder 16X16 ADJUSTABLE FOR SUPPORT CENTRAL GILD.GM35 POS.1-4 IT: PORTAUTENSILE 16X16 REGOLABILE DA SUPPORTO CENTRALE GILD.GM35 POS.1-4	
4035004	tool holder 16X16 ADJUSTABLE FOR SUPPORT CENTRAL GILD.GM35 POS.2-5 IT: PORTAUTENSILE 16X16 REGOLABILE DA SUPPORTO CENTRALE GILD.GM35 POS.2-5	
4035001	tool holder 16X16 FOR SUPPORT CENTRAL GILD.GM35 POS.1-4 IT: PORTAUTENSILE 16X16 DA SUPPORTO CENTRALE GILD.GM35 POS.1-4	
4035002	tool holder 16X16 FOR SUPPORT CENTRAL GILD.GM35 POS.2-5 IT: PORTAUTENSILE 16X16 DA SUPPORTO CENTRALE GILD.GM35 POS.2-5	
Mechanical Transmission		117
2001D356	BELT MOTOR 60HZ for GILD.GM35 IT: CINGHIA MOTORE 60HZ x GILD.GM35	
2001D351	BELT MOTOR XPA 1700 GILD.GM32/35 (10.31.64) IT: CINGHIA MOTORE XPA 1700 GILD.GM32/35 (10.31.64)	
2001D381	BELT ROFLEX RE-X SPA 1782 IT: CINGHIA ROFLEX RE-X SPA 1782	
2001D382	BELT ROFLEX RE-X SPA 1800 (10.31.32) IT: CINGHIA ROFLEX RE-X SPA 1800 (10.31.32)	
2001D377	BELT ROFLEX SPA 1700 MOTOR GILD.GM32/42 IT: CINGHIA ROFLEX SPA 1700 MOTORE GILD.GM32/42	
4913129	BRACKET for WHEEL HATCH IT: STAFFA x RUOTA PORTELLONE	
2002R016	BUSHING TAPER LOCK 1210 DIA..24 FOR PULLEY MOTOR FEEDS GILD.GM35 AC (10.24.65) IT: BUSSOLA TAPER LOCK 1210 DIAM.24 PER PULEGGIA MOTORE AVANZAMENTI GILD.GM35 AC (10.24.65)	
2002R018	BUSHING TAPER LOCK 1610 DIA..35 FOR PULLEY SHAFT FEEDS GILD.GM35 AC (10.24.66) IT: BUSSOLA TAPER LOCK 1610 DIAM.35 PER PULEGGIA ALBERO AVANZAMENTI GILD.GM35 AC (10.24.66)	
2002R014	BUSHING TAPER LOCK 2012 Ø 42 FOR PULLEY MOTOR GILD.GM32/42 IT: BUSSOLA TAPER LOCK 2012 Ø 42 PER PULEGGIA MOTORE GILD.GM32/42	
3738610	CAM FOR GILD.GM35/6 IT: CAMMA PER GILD.GM35/6	
3738611	CAM FOR GILD.GM35/6 IT: CAMMA PER GILD.GM35/6	
3738616	CAM FOR GILD.GM35/6 IT: CAMMA PER GILD.GM35/6	
3510186	CLUTCH FEEDS GR.23 GILD.GM32/35/42 ORIGINAL ORTLINGHAUS IT: FRIZIONE AVANZAMENTI GR.23 GILD.GM32/35/42 ORIGINALE ORTLINGHAUS	
2245H200	CLUTCH GR.11 for BRAKE PICK-UP GILD.GM32/35/42 (07.23.52 / 77.23.49) IT: FRIZIONE GR.11 x FRENO PICK-UP GILD.GM32/35/42 (07.23.52 / 77.23.49)	
2207278	CLUTCH THREADING GR.27 for GILD.GM32/35/42 ORIGINAL ORTLINGHAUS IT: FRIZIONE FILETTATURA GR.27 x GILD.GM32/35/42 ORIGINALE ORTLINGHAUS	
3525140	CONNECTING ROD IT: BIELLA	

3725164	CONNECTING ROD IT: BIELLA
4922006	CONNECTING ROD IT: BIELLA
3525139	CONNECTING ROD CONTROL AXIAL GILD.GM32/35 IT: BIELLA COMANDO ASSIALE GILD.GM32/35
3711115	CONNECTING ROD CONTROL SUPPORT CENTRAL GILD.GM32/35 IT: BIELLA COMANDO SUPPORTO CENTRALE GILD.GM32/35
4907210	CONNECTING ROD SLIDE RADIAL GILD.GM35 POS.1-2 IT: BIELLA SLITTA RADIALE GILD.GM35 POS.1-2
3507154	CONNECTING ROD for SLIDES GILD.GM32/35 POS.3/6 IT: BIELLA x SLITTE GILD.GM32/35 POS.3/6
3507177	CONNECTING ROD for SLIDES GILD.GM32/35 POS.4/5 IT: BIELLA x SLITTE GILD.GM32/35 POS.4/5
4923152	COUPLING IT: GIUNTO
4223107	COUPLING (SC5254123) IT: GIUNTO (SC5254123)
3501150	GEAR CENTRAL Z54 for GILD.GM32/35 IT: INGRANAGGIO CENTRALE Z54 x GILD.GM32/35
3510200	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=23 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=23
3510201	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=24 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=24
3510202	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=25 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=25
3510203	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=26 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=26
3510204	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=29 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=29
3510205	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=30 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=30
3510206	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=31 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=31
3510207	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=32 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=32
3510208	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=33 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=33
3510209	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=35 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=35
3510210	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=37 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=37
3510211	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=39 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=39
3510212	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=41 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=41
3510213	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=43 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=43
3510228	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=45 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=45
3510214	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=48 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=48
3510215	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=50 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=50
3510216	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=52 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=52

3510217	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=54 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=54
3510218	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=56 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=56
3510219	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=58 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=58
3510220	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=59 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=59
3510221	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=60 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=60
3510222	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=61 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=61
3510223	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=62 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=62
3510224	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=65 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=65
3510225	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=66 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=66
3510226	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=67 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=67
3510227	GEAR REVOLUTIONS/FEEDS GILD.GM32/42 Z=68 IT: INGRANAGGIO GIRI/AVANZAMENTI GILD.GM32/42 Z=68
3501117	GEAR SATELLITE GEAR Z36 for GILD.GM32/35 IT: INGRANAGGIO SATELLITE Z36 x GILD.GM32/35
3507117	GRUB SCREW M10 for STOP CARRIAGE RADIAL GM32/35/42 - SHAFTS cam carrier GM16 IT: GRANO M10 x FERMO CARRO RADIALE GM32/35/42 - ALBERI PORTACAMME GM16
3517103	HALF-COUPLING FINISHED for PUMP LUBRICATION A RECIRCULATION GM32 IT: SEMIGIUNTO FINITO x POMPA LUBRIFICAZIONE A RICIRCOLO GM32
4904101	KEY FOR cam carrier shaft AUXILIARY GILD.GM35 IT: LINGUETTA PER ALBERO PORTACAMME AUSILIARIO GILD.GM35
3501162	KEY SHAFT CENTRAL GILD.GM35 IT: CHIAVETTA ALBERO CENTRALE GILD.GM35
2010H032	KEYING TOOL for PULLEY MOTOR FEEDS GM35 (10.24.65) IT: CALETTATORE x PULEGGIA MOTORE AVANZAMENTI GM35 (10.24.65)
3510CP	PAIR GEARS REVOLUTIONS/FEEDS GILD.GM32/42 IT: COPPIA INGRANAGGI GIRI/AVANZAMENTI GILD.GM32/42
3722122	PIN for CAMS FRONT GILD. GM32/35/42 L=47,5 (30011503) IT: PERNO x CAMME FRONTALI GILD. GM32/35/42 L=47,5 (30011503)
3507127	PIN for CAMS RADIAL GILD.GM32/35 L=40mm IT: PERNO x CAMME RADIALI GILD.GM32/35 L=40mm
2002R013	PULLEY MOTOR GILD.GM32/42 IT: PULEGGIA MOTORE GILD.GM32/42
4918115	PULLEY MOTOR MAIN GILD.GM35 IT: PULEGGIA MOTORE PRINCIPALE GILD.GM35
2002R012	PULLEY REVOLUTIONS GILD.GM32/35/42 (10.60.92) IT: PULEGGIA GIRI GILD.GM32/35/42 (10.60.92)
2002R015	PULLEY TOOTHED 20 H150 TAPER LOCK FOR MOTOR FEEDS GILD.GM35 AC IT: PULEGGIA DENTATA 20 H150 TAPER LOCK PER MOTORE AVANZAMENTI GILD.GM35 AC
2002R017	PULLEY TOOTHED 30 H150 TAPER LOCK FOR SHAFT FEEDS GILD.GM35 AC (10.60.86) IT: PULEGGIA DENTATA 30 H150 TAPER LOCK PER ALBERO AVANZAMENTI GILD.GM35 AC (10.60.86)
3522116	ROLLER for CAMS RADIAL/FRONT/AXIAL GILD.GM32/35/42 (30011504) IT: RULLO x CAMME RADIALI/FRONTALI/ASSIALI GILD.GM32/35/42 (30011504)
3507128	SCREW ADJUSTMENT BOTTOM CAMS GILD.GM32/35/42 IT: VITE REGOLAZIONE FONDO CAMME GILD.GM32/35/42
3711120	SCREW FASTENING CAMS SUPPORT CENTRAL GILD. GM32/35/42 IT: VITE FISSAGGIO CAMME SUPPORTO CENTRALE GILD. GM32/35/42

3706120	SCREW for FASTENING CAMS GILD.GM32/35/42 IT: VITE x FISSAGGIO CAMME GILD.GM32/35/42
3523108	SHAFT IT: ALBERO
3722101	SHAFT IT: ALBERO
3723103	SHAFT IT: ALBERO
3723108	SHAFT IT: ALBERO
3723200	SHAFT IT: ALBERO
4910164	SHAFT IT: ALBERO
3523122	SHAFT INTERMEDIATE IT: ALBERO INTERMEDIO
3723005	SHAFT INTERMEDIATE for GILD.GM32/35/42 IT: ALBERO INTERMEDIO x GILD.GM32/35/42
4922101	SHAFT SPLINED for GILD.GM32/35 IT: ALBERO SCANALATO x GILD.GM32/35
3723006	TAKE-OFF MOTION for SHAFT INTERMEDIATE for GILD.GM32/35/42 IT: PRESA MOTO x ALBERO INTERMEDIO x GILD.GM32/35/42
3523107	WEDGE for CLUTCH THREADING IT: CUNEO x FRIZIONE FILETTATURA
3504105	WHEEL IT: RUOTA
3504106	WHEEL IT: RUOTA
3504114	WHEEL IT: RUOTA
3504142	WHEEL IT: RUOTA
3507125	WHEEL IT: RUOTA
3510156	WHEEL IT: RUOTA
3510164	WHEEL IT: RUOTA
3510170	WHEEL IT: RUOTA
3510175	WHEEL IT: RUOTA
3510180	WHEEL IT: RUOTA
3510182	WHEEL IT: RUOTA
3522125	WHEEL IT: RUOTA
3710112	WHEEL IT: RUOTA
3723106	WHEEL IT: RUOTA
3723107	WHEEL IT: RUOTA
3723113	WHEEL IT: RUOTA

4910158	WHEEL IT: RUOTA
4910159	WHEEL IT: RUOTA
4910162	WHEEL IT: RUOTA
4910163	WHEEL DOUBLE IT: RUOTA DOPPIA
3710118	WHEEL DOUBLE (3710119 + 3510174) IT: RUOTA DOPPIA (3710119 + 3510174)
4906104	WHEEL HELICAL IN BRONZE HELIX LEFT for GM32/35/42 (35.06.113) IT: RUOTA ELICOIDALE IN BRONZO ELICA SINISTRA x GM32/35/42 (35.06.113)
4906103	WHEEL HELICAL IN BRONZE HELIX RIGHT MDR for GM32/35/42 (35.06.112) IT: RUOTA ELICOIDALE IN BRONZO ELICA DESTRA MDR x GM32/35/42 (35.06.112)
3713172	WHEEL REAR GILD.GM32/35 IT: RUOTA POSTERIORE GILD.GM32/35
3704106	WHEEL TOOTHED FOR cam carrier shaft AUXILIARY GILD.GM32/35 IT: RUOTA DENTATA PER ALBERO PORTACAMME AUSILIARIO GILD.GM32/35
4904105	WHEEL TOOTHED FOR cam carrier shaft AUXILIARY GILD.GM35 AC IT: RUOTA DENTATA PER ALBERO PORTACAMME AUSILIARIO GILD.GM35 AC
3723136	WHEEL Z=27 IT: RUOTA Z=27
3723201	WHEEL Z=35 IT: RUOTA Z=35
3723202	WHEEL Z=35 IT: RUOTA Z=35
3723135	WHEEL Z=36 IT: RUOTA Z=36
3760278	WHEEL Z=44 for N.4 POSITIONING A 90° IT: RUOTA Z=44 x N.4 POSIZIONAMENTI A 90°
4906118	cam carrier GILD.GM32/35/42 ROTATION CLOCKWISE (37.06.118+37.06.119) IT: PORTACAMMA GILD.GM32/35/42 ROTAZIONE ORARIA (37.06.118+37.06.119)
4906119	cam carrier GILD.GM32/35/42 ROTATION COUNTER-CLOCKWISE (37.06.116+37.06.117) IT: PORTACAMMA GILD.GM32/35/42 ROTAZIONE ANTIORARIA (37.06.116+37.06.117)

Feed, Control & Slides		79
3725129	ANGLE BRACKET FOR CONTROL SLIDE AXIAL GILD.GM32/35/42 POS.4-5 IT: SQUADRA PER COMANDO SLITTA ASSIALE GILD.GM32/35/42 POS.4-5	
4925146	BLOCK CONTROL AXIAL GILD.GM35 POS.1-2 IT: BLOCCHETTO COMANDO ASSIALE GILD.GM35 POS.1-2	
4925125	BLOCK CONTROL AXIAL GILD.GM35 POS.1-2-4-5 IT: BLOCCHETTO COMANDO ASSIALE GILD.GM35 POS.1-2-4-5	
4925124	BLOCK CONTROL AXIAL GILD.GM35 POS.4-5 IT: BLOCCHETTO COMANDO ASSIALE GILD.GM35 POS.4-5	
3707107	BLOCK for LEVER RADIAL GM32/35/42 POS.1 IT: BLOCCHETTO x LEVA RADIALE GM32/35/42 POS.1	
3707116	BLOCK for LEVER RADIAL GM32/35/42 POS.2 IT: BLOCCHETTO x LEVA RADIALE GM32/35/42 POS.2	
3507155	BLOCK for LEVER RADIAL GM32/35/42 POS.3 IT: BLOCCHETTO x LEVA RADIALE GM32/35/42 POS.3	
3507178	BLOCK for LEVER RADIAL GM32/35/42 POS.4 IT: BLOCCHETTO x LEVA RADIALE GM32/35/42 POS.4	
3507185	BLOCK for LEVER RADIAL GM32/35/42 POS.5 IT: BLOCCHETTO x LEVA RADIALE GM32/35/42 POS.5	

3507164	BLOCK for LEVER RADIAL GM32/35/42 POS.6 IT: BLOCCHETTO x LEVA RADIALE GM32/35/42 POS.6
4907152	BLOCK for LEVER RADIAL GM35 HIRTH POS.1 IT: BLOCCHETTO x LEVA RADIALE GM35 HIRTH POS.1
4907155	BLOCK for LEVER RADIAL GM35 HIRTH POS.2 IT: BLOCCHETTO x LEVA RADIALE GM35 HIRTH POS.2
4907191	BODY LEVER GM35 HIRTH POS.3 IT: CORPO LEVA GM35 HIRTH POS.3
3504116	BRONZE BUSHING for PINION ECCENTRIC TRANSLATION MOTION IT: BRONZINA x PIGNONE ECCENTRICO TRASLAZIONE
3511132	BUSHING FOR LEVER CONTROL SUPPORT CENTRAL GILD.GM35 IT: BOCCOLA PER LEVA COMANDO SUPPORTO CENTRALE GILD.GM35
3507122	BUSHING IN BRONZE for LEVERS GILD. GM32/35 IT: BOCCOLA IN BRONZO x LEVE GILD. GM32/35
3507156	BUSHING IN BRONZE for LEVERS GILD.GM32/35/42 IT: BOCCOLA IN BRONZO x LEVE GILD.GM32/35/42
4911002	CONTROL SUPPORT CENTRAL GILD.GM35 IT: COMANDO SUPPORTO CENTRALE GILD.GM35
4211010	CONTROL SUPPORT CENTRAL GILD.GM35/8 IT: COMANDO SUPPORTO CENTRALE GILD.GM35/8
4925117	COUPLING SLIDE POS.1 IT: ACCOPPIAMENTO SLITTA POS.1
4925118	COUPLING SLIDE POS.2 IT: ACCOPPIAMENTO SLITTA POS.2
4925119	COUPLING SLIDE POS.4 IT: ACCOPPIAMENTO SLITTA POS.4
4925120	COUPLING SLIDE POS.5 IT: ACCOPPIAMENTO SLITTA POS.5
4205001	CYLINDER RELEASE DRUM GM35-6 IT: CILINDRO SBLOCCAGGIO TAMBURO GM35-6
3709108	DISC TERMINAL FOR CONTROL SUPPORT CENTRAL GILD.GM35 IT: DISCO TERMINALE PER COMANDO SUPPORTO CENTRALE GILD.GM35
3709109	DISC TERMINAL FOR CONTROL SUPPORT CENTRAL GILD.GM35 (37.07.109) IT: DISCO TERMINALE PER COMANDO SUPPORTO CENTRALE GILD.GM35 (37.07.109)
3715148	FEELER IT: TASTATORE
4907114	GUARD SLIDE RADIAL GILD.GM35 POS.1 IT: PROTEZIONE SLITTA RADIALE GILD.GM35 POS.1
3707157	GUARD SLIDE RADIAL GILD.GM35 POS.1-2 IT: RIPARO SLITTA RADIALE GILD.GM35 POS.1-2
4907115	GUARD SLIDE RADIAL GILD.GM35 POS.2 IT: PROTEZIONE SLITTA RADIALE GILD.GM35 POS.2
4907147	GUARD SLIDE RADIAL GILD.GM35 POS.3 IT: PROTEZIONE SLITTA RADIALE GILD.GM35 POS.3
4907151	GUARD SLIDE RADIAL GILD.GM35 POS.6 IT: PROTEZIONE SLITTA RADIALE GILD.GM35 POS.6
3707110	GUARD for SLIDE RADIAL GILD.GM32/35 POS.1/2 IT: PROTEZIONE x SLITTA RADIALE GILD.GM32/35 POS.1/2
4912103	LEVER (37.12.107) IT: LEVA (37.12.107)
3707114	LEVER RADIAL GM32-35-42 POS.1 IT: LEVA RADIALE GM32-35-42 POS.1
3707115	LEVER RADIAL GM32-35-42 POS.2 IT: LEVA RADIALE GM32-35-42 POS.2
3507143	LEVER RADIAL GM32-35-42 POS.3 IT: LEVA RADIALE GM32-35-42 POS.3

3507173	LEVER RADIAL GM32-35-42 POS.4 (49.07.159) IT: LEVA RADIALE GM32-35-42 POS.4 (49.07.159)
3507184	LEVER RADIAL GM32-35-42 POS.5 (49.07.160) IT: LEVA RADIALE GM32-35-42 POS.5 (49.07.160)
3507161	LEVER RADIAL GM32-35-42 POS.6 IT: LEVA RADIALE GM32-35-42 POS.6
4907198	LEVER RADIAL GM35 HIRTH POS.1 IT: LEVA RADIALE GM35 HIRTH POS.1
4907201	LEVER RADIAL GM35 HIRTH POS.2 IT: LEVA RADIALE GM35 HIRTH POS.2
4907146	LEVER RADIAL GM35 HIRTH POS.3 IT: LEVA RADIALE GM35 HIRTH POS.3
4907150	LEVER RADIAL GM35 HIRTH POS.6 IT: LEVA RADIALE GM35 HIRTH POS.6
3511119	PIN CONTROL SUPPORT CENTRAL GILD.GM32/35 IT: PERNO COMANDO SUPPORTO CENTRALE GILD.GM32/35
3511122	PIN CONTROL SUPPORT CENTRAL GILD.GM32/35 IT: PERNO COMANDO SUPPORTO CENTRALE GILD.GM32/35
3711111	PIN CONTROL SUPPORT CENTRAL GILD.GM32/35 IT: PERNO COMANDO SUPPORTO CENTRALE GILD.GM32/35
3725112	PIN GILD.GM32/35/42 for LEVER THRUST AXIAL IT: PERNO GILD.GM32/35/42 x LEVA SPINTA ASSIALE
4907111	PIN GILD.GM32/35/42 for SLIDES RADIAL L=40 (VERSION FOR ROLLER WITH 27 NEEDLE BEARINGS) IT: PERNO GILD.GM32/35/42 x SLITTE RADIALI L=40 (VERSIONE PER RULLO CON 27 AGHI)
3711112	PIN for CONTROL SUPPORT CENTRAL GILD.GM32/35/42 IT: PERNO x COMANDO SUPPORTO CENTRALE GILD.GM32/35/42
3507121	PIN for LEVERS RADIAL GILD. GM32/35 POS.1/2 IT: PERNO x LEVE RADIALI GILD. GM32/35 POS.1/2
3507157	PIN for LEVERS RADIAL GILD. GM32/35/42 POS.3/4/5/6 IT: PERNO x LEVE RADIALI GILD. GM32/35/42 POS.3/4/5/6
3504113	PINION ECCENTRIC for TRANSLATION MOTION GM32/35 IT: PIGNONE ECCENTRICO x TRASLAZIONE GM32/35
4907122	PLATE FOR SLIDE RADIAL GILD.GM35 POS.3/6 IT: PIASTRA PER SLITTA RADIALE GILD.GM35 POS.3/6
4907123	PLATE FOR SLIDE RADIAL POS.1-2-4-5 GILD.GM32/35 IT: PIASTRA PER SLITTA RADIALE POS.1-2-4-5 GILD.GM32/35
4907167	PLATE SLIDE RADIAL GILD.GM35 POS.4-5 IT: PIASTRA SLITTA RADIALE GILD.GM35 POS.4-5
3507104	PLATE STANDARD FOR SLIDES RADIAL GILD.GM32/35/42 IT: PIASTRA STANDARD PER SLITTE RADIALI GILD.GM32/35/42
3501129	RING for SLEEVE lever holder GILD. GM32/35 IT: ANELLO x MANICOTTO PORTALEVETTE GILD. GM32/35
4212137	ROD IT: ASTA
4205103	ROD CLAMPING DRUM GILD.GM35 IT: STELO BLOCCAGGIO TAMBURRO GILD.GM35
3711113	ROLLER for CONTROL SUPPORT CENTRAL GILD.GM32/35/42 IT: RULLO x COMANDO SUPPORTO CENTRALE GILD.GM32/35/42
3504115	ROLLER for PINION ECCENTRIC TRANSLATION MOTION IT: RULLO x PIGNONE ECCENTRICO TRASLAZIONE
3525114	SCREW ADJUSTMENT GIB SLIDE AXIAL GILD.GM35 POS.2-4 IT: VITE REGOLAZIONE LARDONE SLITTA ASSIALE GILD.GM35 POS.2-4
3307125	SCREW FOR SLIDE RADIAL POS.1-2-3-4-5 GILD.GM35 IT: VITE PER SLITTA RADIALE POS.1-2-3-4-5 GILD.GM35
4907168	SCREW M12for1 STOP SLIDES RADIAL GM35 IT: VITE M12x1 FERMO SLITTE RADIALI GM35

4907144	SCREW SLIDE RADIAL GILD.GM32/35/42 POS.3-6 IT: VITE SLITTA RADIALE GILD.GM32/35/42 POS.3-6
3707118	SCREW SLIDE RADIAL GILD.GM35 POS.3-6 IT: VITE SLITTA RADIALE GILD.GM35 POS.3-6
3507105	SCREW for ADJUSTMENT GIB SLIDE RADIAL POS.1-2-4-5 IT: VITE x REGOLAZIONE LARDONE SLITTA RADIALE POS.1-2-4-5
3501131	SLEEVE lever holder GILD.GM32/35 IT: MANICOTTO PORTALEVETTE GILD.GM32/35
4925103	SLIDE IT: SLITTA
4925105	SLIDE IT: SLITTA
4925106	SLIDE IT: SLITTA
4925019	SLIDE AXIAL GILD.GM32/35/42 POS.1 SLOTS A T IT: SLITTA ASSIALE GILD.GM32/35/42 POS.1 CAVE A T
4925020	SLIDE AXIAL GILD.GM32/35/42 POS.2 SLOTS A T IT: SLITTA ASSIALE GILD.GM32/35/42 POS.2 CAVE A T
4925017	SLIDE AXIAL GILD.GM32/35/42 POS.4 SLOTS A T IT: SLITTA ASSIALE GILD.GM32/35/42 POS.4 CAVE A T
4925018	SLIDE AXIAL GILD.GM32/35/42 POS.5 SLOTS A T IT: SLITTA ASSIALE GILD.GM32/35/42 POS.5 CAVE A T
3504118	SPACER for PINION ECCENTRIC TRANSLATION MOTION IT: DISTANZIALE x PIGNONE ECCENTRICO TRASLAZIONE
3707144	VERNIER FOR CARRIAGE RADIAL GILD.GM35 POS.1-2-3-6 IT: NONIO PER CARRO RADIALE GILD.GM35 POS.1-2-3-6
3707143	VERNIER FOR CARRIAGE RADIAL GILD.GM35 POS.4-5 IT: NONIO PER CARRO RADIALE GILD.GM35 POS.4-5

Pneumatics & Hydraulics 3

4205101	CYLINDER IT: CILINDRO
4205102	PISTON IT: PISTONE
4951188	PISTON IT: PISTONE

Motors & Electrical/Electronic 1

2489P006	ANTI-VIBRATION MOUNT for MOTOR GM32/35 741092 (10.35.20) IT: ANTIVIBRANTE x MOTORE GM32/35 741092 (10.35.20)
----------	---

Bearings, Rings & Rotating Components 19

3758189	BUSHING IT: BOCCOLA
4304113	BUSHING IT: BOCCOLA
4923141B	BUSHING (Hole 61,4mm) IT: BOCCOLA (Foro 61,4mm)
4923141	BUSHING (SC5254121) IT: BOCCOLA (SC5254121)
3501119	BUSHING FOR REST SMALL HAMMER GILD. GM32/35 IT: BOCCOLA PER APPOGGIO MARTELLETTO GILD. GM32/35

3501140	BUSHING SPLINED for GILD.GM32/35 IT: BOCCOLA SCANALATA x GILD.GM32/35
3701231	BUSHING SPLINED for GILD.GM32/35/42 IT: BOCCOLA SCANALATA x GILD.GM32/35/42
4001159	BUSHING for REST SMALL HAMMER GILD.GM42 IT: BOCCOLA x APPOGGIO MARTELLETTO GILD.GM42
3701107	DISC stop holder (SECTOR) for DRUM GM32/35/42 IT: DISCO PORTAFERMI (SETTORE) x TAMBURRO GM32/35/42
4901235	DISC stop holder (SECTOR) for DRUM GM35/42 HIRTH IT: DISCO PORTAFERMI (SETTORE) x TAMBURRO GM35/42 HIRTH
3704114	DRUM IT: TAMBURRO
3701106	GASKET for DRUM GM32/35 COMPLETE OF OR IT: GUARNIZIONE x TAMBURRO GM32/35 COMPLETA DI OR
4925101	PIN for THRUST AXIAL GILD. GM32/35 IT: PERNO x SPINTA ASSIALE GILD. GM32/35
3525123	PIN for THRUST AXIAL GILD. GM32/35/42 L=55 IT: PERNO x SPINTA ASSIALE GILD. GM32/35/42 L=55
4901129	PLUG X BOOT COVER DRUM GM32-35-42 IT: TAPPO X CUFFIA TAMBURRO GM32-35-42
3501138	RING IT: ANELLO
3758205	RING IT: ANELLO
4958112	RING IT: ANELLO
2236118	ROLLER DRUM GILD.GM35 STOP IT: RULLO TAMBURRO GILD.GM35 STOP

Springs & Elastic Components		20
4901003	PACK SPRINGS A CUP for GILD. GM32/35 IT: PACCO MOLLE A TAZZA x GILD. GM32/35	
4901009	PACK SPRINGS A CUP for GILD. GM42 IT: PACCO MOLLE A TAZZA x GILD. GM42	
4001118	SLEEVE CARRIER SPRINGS A CUP IT: MANICOTTO PORTA MOLLE A TAZZA	
4035107	SPRING IT: MOLLA	
4925121	SPRING IT: MOLLA	
3722123	SPRING (30010211) IT: MOLLA (30010211)	
3701120	SPRING A CUP IT: MOLLA A TAZZA	
2130H060	SPRING A CUP (1) GILD. GM32/35 (10.54.90) IT: MOLLA A TAZZA (1) GILD. GM32/35 (10.54.90)	
2129H078	SPRING A TRACTION IT: MOLLA A TRAZIONE	
4001152	SPRING CUP for GILD.GM42 IT: MOLLA TAZZA x GILD.GM42	
3707158	SPRING GUIDE CH=11 IT: GUIDAMOLLA CH=11	
3507119	SPRING GUIDE CH=13 IT: GUIDAMOLLA CH=13	

4925113	SPRING GUIDE CH=6 IT: GUIDAMOLLA CH=6
3525111	SPRING GUIDE CH=7 IT: GUIDAMOLLA CH=7
3505129	SPRING LATCH IT: MOLLA CHIAVISTELLO
2129H076	SPRING X CARRIAGES GILD.GM32/35/42 POS.1-2-3-6 (11.75.80) IT: MOLLA X CARRI GILD.GM32/35/42 POS.1-2-3-6 (11.75.80)
2129H077	SPRING X CARRIAGES GILD.GM32/35/42 POS.4-5 (11.76.40) IT: MOLLA X CARRI GILD.GM32/35/42 POS.4-5 (11.76.40)
3725220	SPRING for CARRIAGES A CROSS GILD.GM32/35 IT: MOLLA x CARRI A CROCE GILD.GM32/35
3707131	SPRING for CARRIAGES GILD.GM32/35/42 (POS.1-2-3-6) IT: MOLLA x CARRI GILD.GM32/35/42 (POS.1-2-3-6)
3507118	SPRING for CARRIAGES GILD.GM32/35/42 POS.4-5 IT: MOLLA x CARRI GILD.GM32/35/42 POS.4-5

Fasteners & Small Parts 44

4925111	GIB IT: LARDONE
4925112	GIB IT: LARDONE
3504124	INSERT IT: TASSELLO
36930016	INSERT IT: TASSELLO
36930090	INSERT IT: TASSELLO
3501163	KEY IT: CHIAVETTA
3758190	KEY IT: CHIAVETTA
4923110	KEY IT: CHIAVETTA
3522134	KEY for GILD.GM32/35 IT: CHIAVETTA x GILD.GM32/35
3501157	NUT IT: DADO
3723157	NUT IT: DADO
3501110	PIN IT: SPINA
3707151	PIN IT: SPINA
3725224	PIN IT: PERNO
3760183	PIN IT: PERNO
4035104	PIN IT: PERNO
2608F014	PIN NADELLA G0009016 GC30 L=44,5 (06.67.91) IT: PERNO NADELLA G0009016 GC30 L=44,5 (06.67.91)
2608F016	PIN NADELLA G0009018 GC30 L=50 (06.67.92) IT: PERNO NADELLA G0009018 GC30 L=50 (06.67.92)

2608F012	PIN NADELLA G9901021 GC30 L=40 (06.67.93) IT: PERNO NADELLA G9901021 GC30 L=40 (06.67.93)
2608F013	PIN NADELLA G9907024 GC30 L=48,5 (06.67.94) IT: PERNO NADELLA G9907024 GC30 L=48,5 (06.67.94)
2608F015	PIN NADELLA G9907025 L=55 (06.67.96) IT: PERNO NADELLA G9907025 L=55 (06.67.96)
3503111	PIN for GILD.GM32/35 IT: PERNO x GILD.GM32/35
3505125	PIN for GILD.GM32/35 IT: PERNO x GILD.GM32/35
3507176	PIN for GILD.GM32/35 IT: PERNO x GILD.GM32/35
3507153	PIN for GILD.GM32/35/42 IT: PERNO x GILD.GM32/35/42
3707105	PIN for GILD.GM32/35/42 IT: PERNO x GILD.GM32/35/42
3501156	SCREW IT: VITE
3526127	SCREW IT: VITE
3707108	SCREW IT: VITE
3714129	SCREW IT: VITE
4035105	SCREW IT: VITE
4035106	SCREW IT: VITE
4907148	SCREW IT: VITE
4923130	SCREW IT: VITE
4923131	SCREW IT: VITE
4923134	SCREW IT: VITE
4925129	SCREW IT: VITE
3713120B	SCREW M8for45 TURNED for PANELS IT: VITE M8x45 TORNITA x SPORTELLI
3713120	SCREW M8for60 TURNED for PANELS IT: VITE M8x60 TORNITA x SPORTELLI
4212103	SCREW OF ADJUSTMENT IT: VITE DI REGOLAZIONE
3701137	SCREW for STOP C (Complete of pad 37.01.136) IT: VITE x FERMO C (Completa di pasticca 37.01.136)
3507180	SCREW for STOP POS.4/5 IT: VITE x FERMO POS.4/5
3510149	WASHER IT: RONDELLA
3526128	WASHER IT: RONDELLA

4925133	ANGLE BRACKET IT: SQUADRA
4925134	ANGLE BRACKET IT: SQUADRA
4925135	ANGLE BRACKET IT: SQUADRA
4943134	ANGLE BRACKET IT: SQUADRA
4916124	ANGLE BRACKET (SC5254126) IT: SQUADRA (SC5254126)
3503103	BLOCK IT: BLOCCETTO
3525118	BLOCK IT: BLOCCETTO
4035102	BLOCK IT: BLOCCETTO
4951190	BLOCK IT: BLOCCETTO
3502108	BRACKET IT: STAFFA
4035103	BRACKET IT: STAFFA
4035109	BRACKET IT: STAFFA
4035114	BRACKET IT: STAFFA
4914105	BRACKET BUNDLE COVER GILD.GM32/35/42 IT: STAFFA COPRIFASCIO GILD.GM32/35/42
3504138	CROSS OF MALTA for GILD. GM32/35 IT: CROCE DI MALTA x GILD. GM32/35
3510152	FLANGE IT: FLANGIA
3523112	FLANGE IT: FLANGIA
3722108	FLANGE IT: FLANGIA
3722124	FLANGE IT: FLANGIA
3723172	FLANGE IT: FLANGIA
4923106	FLANGE IT: FLANGIA
4923147	FLANGE IT: FLANGIA
4223102	FLANGE FRONT IT: FLANGIA ANTERIORE
3701177	FLANGE GILD.GM32 IT: FLANGIA GILD.GM32
4223103	FLANGE REAR (SC5254120) IT: FLANGIA POSTERIORE (SC5254120)
4904117	FORK IT: FORCELLA
3504112	FORK for CROSS OF MALTA IT: FORCELLA x CROCE DI MALTA
3723102	PLATE IT: PIASTRA

4925102	PLATE IT: PIASTRA
4925104	PLATE IT: PIASTRA
4925116	PLATE IT: PIASTRA
4925130	PLATE IT: PIASTRA
4925131	PLATE IT: PIASTRA
4925132	PLATE IT: PIASTRA
3714128	SECTOR IN FIBER BUNDLE TUBES GILD. GM32-35-42 IT: SETTORE IN FIBRA FASCIO TUBI GILD. GM32-35-42
3501137	SLEEVE IT: MANICOTTO
4201345	SLEEVE GILD.GM35/8-GMC35 IT: MANICOTTO GILD.GM35/8-GMC35
4001162	SLEEVE GILDEMEISTER GM42 IT: MANICOTTO GILDEMEISTER GM42
3504117	SPACER IT: DISTANZIALE
3510150	SPACER IT: DISTANZIALE
3522109	SPACER IT: DISTANZIALE
3523116	SPACER IT: DISTANZIALE
3523118	SPACER IT: DISTANZIALE
3523138	SPACER IT: DISTANZIALE
3701119	SPACER IT: DISTANZIALE
3703103	SPACER IT: DISTANZIALE
3723109	SPACER IT: DISTANZIALE
3723111	SPACER IT: DISTANZIALE
3723112	SPACER IT: DISTANZIALE
3723204	SPACER IT: DISTANZIALE
3723205	SPACER IT: DISTANZIALE
3723206	SPACER IT: DISTANZIALE
3758187	SPACER IT: DISTANZIALE
4001160	SPACER IT: DISTANZIALE
4923107	SPACER IT: DISTANZIALE
4923145	SPACER IT: DISTANZIALE

1047411B	SPACER (35.23.124) IT: DISTANZIALE (35.23.124)
3501136	SPACER GM32/35 H=5 IT: DISTANZIALE GM32/35 H=5
3501136H75	SPACER GM32/35 H=7.5 IT: DISTANZIALE GM32/35 H=7.5
3701119S	SPACER OVERSIZED IT: DISTANZIALE MAGGIORATO
4035110	SUPPORT IT: SUPPORTO
4035112	SUPPORT IT: SUPPORTO
4223106	SUPPORT IT: SUPPORTO
4951162	SUPPORT IT: SUPPORTO
4951163	SUPPORT IT: SUPPORTO
4951187	SUPPORT IN BRONZE IT: SUPPORTO IN BRONZO

Miscellaneous / Special Components	45
------------------------------------	----

2489F033	ADHESIVE "DEMA GRD 642 GM" COLOR BLACK 48for17 IT: ADESIVO "DEMA GRD 642 GM" COLORE NERO 48x17
2489F034	ADHESIVE "DEMA GRD 642 GM" COLOR WHITE 48for17 IT: ADESIVO "DEMA GRD 642 GM" COLORE BIANCO 48x17
2489F017	ADHESIVE "GM32 GILDEMEISTER" COLOR WHITE 48for17 IT: ADESIVO "GM32 GILDEMEISTER" COLORE BIANCO 48x17
2489F019	ADHESIVE "GM32-6-GILDEMEISTER" COLOR BLACK 42for14,5 IT: ADESIVO "GM32-6-GILDEMEISTER" COLORE NERO 42x14,5
2489F018	ADHESIVE "GM32-6-GILDEMEISTER" COLOR WHITE 42for14,5 IT: ADESIVO "GM32-6-GILDEMEISTER" COLORE BIANCO 42x14,5
2489F022	ADHESIVE "GM35 AC GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GM35 AC GILDEMEISTER" COLORE NERO 48x17
2489F058	ADHESIVE "GM35 AC GILDEMEISTER" COLOR WHITE 48for17 IT: ADESIVO "GM35 AC GILDEMEISTER" COLORE BIANCO 48x17
2489F020	ADHESIVE "GM35 GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GM35 GILDEMEISTER" COLORE NERO 48x17
2489F021	ADHESIVE "GM35 GILDEMEISTER" COLOR WHITE 48for17 IT: ADESIVO "GM35 GILDEMEISTER" COLORE BIANCO 48x17
2489F023	ADHESIVE "GM35-6 GILDEMEISTER" COLOR BLACK 63for8,5 IT: ADESIVO "GM35-6 GILDEMEISTER" COLORE NERO 63x8,5
2489F026	ADHESIVE "GM42 AC GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GM42 AC GILDEMEISTER" COLORE NERO 48x17
2489F024	ADHESIVE "GM42 GILDEMEISTER" COLOR BLACK 48for17 IT: ADESIVO "GM42 GILDEMEISTER" COLORE NERO 48x17
2489F025	ADHESIVE "GM42 GILDEMEISTER" COLOR WHITE 48for17 IT: ADESIVO "GM42 GILDEMEISTER" COLORE BIANCO 48x17
3760240	BODY POSITIONER IT: CORPO POSIZIONATORE
3722110	BRAKE TAPERED for GILD.GM32/35 IT: FRENO CONICO x GILD.GM32/35
3702109	BUMPER IT: PARACOLPI

3723110	BUSHING IT: BUSSOLA
3713188	CASING COVER THRUST FRONT GILD.GM32 POS.3 IT: CARTER COPERTURA SPINTA FRONTALI GILD.GM32 POS.3
3713189	CASING COVER THRUST FRONT GILD.GM32 POS.6 IT: CARTER COPERTURA SPINTA FRONTALI GILD.GM32 POS.6
3760244	COLUMN IT: COLONNA
3703101	COLUMN for GILD.GM32/35 IT: COLONNA x GILD.GM32/35
3703102	COLUMN for GILD.GM32/35 IT: COLONNA x GILD.GM32/35
3710109	CRANK IT: MANOVELLA
4913278	FRAME REAR GM35 IT: TELAIO POSTERIORE GM35
3706118	HALF-DISC->SEE 49.06.118 IT: SEMIDISCO->VEDI 49.06.118
3706119	HALF-DISC->SEE 49.06.118 IT: SEMIDISCO->VEDI 49.06.118
3706116	HALF-DISC->SEE 49.06.119 IT: SEMIDISCO->VEDI 49.06.119
3706117	HALF-DISC->SEE 49.06.119 IT: SEMIDISCO->VEDI 49.06.119
4913171	HINGE PANELS FRONT GILD.GM32-35 IT: CERNIERA ANTELLI ANTERIORI GILD.GM32-35
3722154	HOOK IT: GANCIO
3722148	HOOK (30260411) IT: GANCIO (30260411)
3722109	JOINT for GILD.GM32/35 IT: SNODO x GILD.GM32/35
4958125	KEY IT: LINGUETTA
4304133	NIPPLE IT: NIPPLO
3717116	OIL SCRAPER GILD.GM32/35 IT: RASCHIAOLIO GILD.GM32/35
3725214	PLUG IT: TAPPO
4311115	PLUG IT: TAPPO
4925115	PLUG IT: TAPPO
4804407	PLUG IN ALUMINUM GM32/35 IT: TAPPO IN ALLUMINIO GM32/35
3501120	SMALL COLUMN for GILD.GM32/35 IT: COLONNINA x GILD.GM32/35
3722120	SMALL DISC IT: DISCHETTO
3725162	STUD IT: PRIGIONIERO
3723104	TUBE IT: TUBO
3510142	WEDGE IT: CUNEO

3510143

WEDGE
IT: CUNEO

Equipment & Tooling Attachments

193 part numbers • price on request

[illegible]

54

—	
—	
Feed, Control & Slides	15
—	
—	
—	
—	
—	
—	
—	
—	
—	
—	
—	
—	
Pneumatics & Hydraulics	4
—	
—	
—	
—	
Fasteners & Small Parts	1
—	
Supports, Plates & Structural Components	4
—	
—	
—	
—	
Miscellaneous / Special Components	33
—	
—	
—	
—	
—	
—	
—	
—	
—	
—	



Tell us what you need.

Send the part number, or describe the component and the machine it belongs to. We reply with price, availability and lead time.

sales@dhg-usa.com

www.dhg-usa.com

DHG Tech Inc.
418 Broadway STE N
Albany, NY 12207
United States

Gildemeister, DMG MORI, Wickman, Schütte, Mori-Say and the machine model designations referenced in this catalogue are trademarks of their respective owners. DHG Tech Inc. is not affiliated with, sponsored by, endorsed by or authorised by those manufacturers. These references are used solely to identify the machines with which the parts and equipment described here are compatible. The products described in this catalogue are independent compatible components and are not original equipment manufacturer parts. Descriptions and specifications are provided in good faith and may be updated without notice; they do not constitute an offer. Prices, lead times and availability are binding only when set out in a written quotation issued by DHG Tech Inc.